



Part number DBW-6062-1

Uses GM part number 10379038 or equivalent*

1960-1962 GM C-10 Truck Drive by wire gas pedal bracket assembly

Instructions:

- Remove factory gas pedal assembly
- Use the two supplied ¼-20 x 1.250" long allen bolts **WITH ANTI-SEIZE** four washers and two nyloc nuts, mock up the bracket by lining up the slotted holes on the pedal bracket with the factory gas pedal mounting bosses on the firewall, the small oval plate bolts on the engine bay side of the firewall and the pedal mounting bracket on the interior side.
- Drill the third gas pedal mounting hole with a ¼" drill bit using the bracket to locate the hole location, after marking the hole location remove the bracket from the firewall and drill hole to ¼" diameter. **Note- Be sure to look for anything you might drill into on the engine bay side of the firewall before drilling!**
- Using supplied Allen bolts, bolt the new bracket to the firewall with washers on the interior bracket side and engine bay side. Tighten the bolts and nyloc nuts.
- Bolt your GM pedal to the bracket on the left side of the bracket using the hardware that came with the pedal.
- Adjust pedal to desired height and tighten bolts, Do not over tighten.
- Installation is now complete

AVS Motorsports

4128 Avenida De La Plata

Oceanside, CA 92056

Toll free: 877-493-7026 - Email: info@avsmotorsports.com

www.Avsmotorsports.com