



Part number DBW-6062-2

Uses GM part number 19417903 or equivalent*

1960-1962 GM C-10 Truck Drive by wire gas pedal bracket assembly

Instructions:

- Remove factory gas pedal assembly
- Use the two supplied ¼-20 x 1.250" long Allen bolts **WITH ANTI-SEIZE** four washers and two nyloc nuts, mock up the bracket by lining up the slotted holes on the pedal bracket with the factory gas pedal mounting bosses on the firewall and make the bracket sit flat on the firewall. The small oval plate bolts on the engine bay side of the firewall and the pedal mounting bracket on the interior side.
- Drill the third and fourth gas pedal mounting hole with a ¼" drill bit using the bracket to locate the hole locations, after marking the hole locations remove the bracket from the firewall and drill hole to ¼" diameter. **Note- Be sure to look for anything you might drill into on the engine bay side of the firewall before drilling!**
- Note the third and fourth mounting holes use the two supplied ¼-20 x 1" Allen bolts with washers and nylocs
- Using the supplied Allen bolts, bolt the new bracket to the firewall with washers on the interior bracket side and engine bay side. Tighten the bolts and nyloc nuts.
- Adjust pedal to desired height and bolt GM part number 19417903 pedal assembly to adjustable gas pedal bracket using the supplied ¼-20 x ¾" Allens washers and nylocs. Be sure to put washers on either side.
- Installation is now complete

AVS Motorsports

4128 Avenida De La Plata

Oceanside, CA 92056

Toll free: 877-493-7026 - Email: info@avsmotorsports.com

www.Avsmotorsports.com