



Part number DBW-6367

Uses GM part number 10379038 or equivalent*

1963-1967 GM Corvette Drive by wire gas pedal bracket assembly

Instructions:

- Remove factory gas pedal
- Follow instructions on supplied drill template form, If missing contact us before proceeding with installation.
- **Be sure to apply Anti-Seize on all mounting hardware to prevent bolts from gulling!**
- Using supplied socket head Allen bolts, bolt the new bracket to the firewall with small washers on the bracket side "Inside of car" and large washer and nyloc on the top engine bay side bolt. Tighten the bolts and nyloc nuts. Note these bolts are intentionally longer to be able to work with thicker insulation or dynamat if being used.
- Loosely bolt pedal to bracket using fasteners supplied by GM, Pedal will be on the outside of bracket or towards the outside of car*
- Adjust pedal to desired height and bolt GM part number 10379038 pedal assembly to adjustable gas pedal bracket, Do not over tighten.
- Installation is now complete

AVS Motorsports

4128 Avenida De La Plata

Oceanside, CA 92056

Toll free: 877-493-7026 - Email: info@avsmotorsports.com

www.Avsmotorsports.com