



Part number DBW-6882-2

Uses GM part number 19417903 or equivalent*

1968-1982 GM Corvette Drive by wire gas pedal bracket assembly

Instructions:

- Remove factory gas pedal assembly
- **Be sure to apply Anti-Seize on all mounting hardware to prevent bolts from gulling!**
- Use the Supplied ¼-20 x 1" long Allen bolts with small washers to mount the new bracket on the firewall lining up the two holes on bracket with the factory gas pedal holes on the firewall.
- Loosely mockup pedal on bracket using supplied 3/4" long Allen bolts and small washers top and bottom and nylocs, Adjust pedal to desired height and bolt GM part number 19417903 pedal assembly to adjustable gas pedal bracket, Do not over tighten.
- Installation is now complete

AVS Motorsports

4128 Avenida De La Plata

Oceanside, CA 92056

Toll free: 877-493-7026 - Email: info@avsmotorsports.com

www.Avsmotorsports.com