

Installation Instructions

Recommended Tools:

- Floor Jack
- Jack Stands
- Ratchet with 14mm, 15mm, 16mm, 17mm, 18mm, 19mm, 21mm, 22mm, 1/2" and 3/4" Sockets and 15mm, 17mm, 19mm and 21mm Wrenches
- Tape Measure
- Mallet



Installation Steps

1. Start by jacking the vehicle up and stabilizing it on the jack stands under the frame with the wheels off the ground.
2. Remove the factory lower control arm.
3. Measure the factory control arms bolt holes from center to center. Using that measurement adjust the G Force control arms to the proper length.
4. Install the new lower control arms.
5. Remove factory upper control arms.
6. Measure the factory control arms bolt holes from center to center. Using that measurement adjust the G Force control arms to the proper length.
7. Install the new upper control arms.



It must be noted that this product is sold for "offroad use only" and customer assumes all risks.