



### Part # 11260398 - 1973-1974 GM "X" Body TQ Series ShockWave System

#### Front Components:

|          |                        |
|----------|------------------------|
| 11163001 | Front ShockWaves       |
| 11162899 | Front Lower StrongArms |
| 11163699 | Front Upper StrongArms |
| 11009300 | Ridetech Tall Spindle  |
| 11169120 | Front SwayBar          |



#### Rear Components:

|          |                   |
|----------|-------------------|
| 11267159 | Rear 4Link System |
| 21150701 | Rear ShockWaves   |

#### Miscellaneous Components:

|          |                |
|----------|----------------|
| 85000000 | Spanner Wrench |
|----------|----------------|

#### Recommended Tools



## 1973-1974 GM "X" Body ShockWave Installation Instructions

#### Table of contents




|                  |                                   |
|------------------|-----------------------------------|
| Pages 2-5.....   | Front ShockWaves                  |
| Pages 6-9.....   | Front Lower StrongArms            |
| Pages 10-15..... | Front Upper StrongArms            |
| Pages 16-18..... | Tall Spindle                      |
| Pages 19-21..... | Front SwayBar                     |
| Pages 22-39..... | Rear 4-Link                       |
| Pages 40-41..... | Rear ShockWaves                   |
| Pages 42.....    | Notes and Care of Your ShockWaves |
| Pages 43-44..... | Shock Adjustment                  |

SOME 1973-1974 X-BODIES CAN HAVE A DIFFERENT REAR FRAME RAIL. SEE PAGE 27.



### Part # 11163011 - GM F-Body & X-Body Front TQ Series Shockwave

#### Recommended Tools



## 1000 Series Bellow, 2.75" Stud/Eye 3.6" Shock Installation Instructions

#### Table of contents

Page 3..... Included Components

Page 4-5..... Shockwave Installation

#### ShockWave Dimensions:

Center of bearing to Center of bearing:

Compressed: 11.05"

Ride Height: 12.88"

Extended: 14.07"


THE DELRIN BALL REQUIRES A 3/4" HOLE FOR THE FLANGE TO GO THROUGH. THIS CAN BE DRILLED WITH A UNIBIT.





### Major Components .....In the box


| Item # | Part #       | Description                                                          | QTY |
|--------|--------------|----------------------------------------------------------------------|-----|
| 1      | 986-10-070   | 3.6" Stroke TQ Series Shock                                          | 2   |
| 2      | 90009989     | 2.75" Stud Top (Installed on Shock) - Includes Adjuster Knob & Screw | 2   |
| 3      | 24090199     | 1000 Series 6.5" Double Convolute AirSpring                          | 2   |
| 4      | 234-00-153   | AirSpring Locking Ring (Installed on shock)                          | 2   |
|        | 99055000     | Locking Ring Set Screw (Installed on shock)                          | 2   |
| 7      | 90002313     | 2.75" Aluminum Stud Top Base                                         | 2   |
| 8      | 90001904     | Bottom Delrin Ball                                                   | 2   |
| 9      | 90001903     | Top Delrin Ball                                                      | 2   |
| 10     | 90001902     | Delrin Ball Aluminum Top Cap                                         | 2   |
| 11     | 99562003     | 9/16"-18 Thin Nylok Nut                                              | 2   |
| 12     | 210-35-120-0 | Adjuster Knob - (90009989 assembly)                                  | 2   |
|        | 90009969     | #4-40 X 1/4" SS, 18-8 Pan Head Torx Cap - (90009989 assembly)        | 2   |
|        | 70012161     | 2.75" Stud Top Metering Rod (installed in stud top)                  | 2   |
| 15     | 90001994     | 5/8" ID Bearing (installed in shock and eyelet)                      | 4   |
| 16     | 90001995     | Bearing Snap Ring (installed in shock and eyelet)                    | 8   |
| 17     | 026-05-000   | Reservoir Mount                                                      | 4   |
| 18     | 99050000     | Reservoir Mounting Screw - 5mm SS X .5 SHCS                          | 12  |
| 19     | 99952006     | Spring Washer                                                        | 2   |
| 20     | 90009908     | High Speed Adjuster Knob                                             | 2   |
| 21     | 90009907     | Low Speed Adjuster Knob                                              | 2   |
| 22     | 99041000     | 4 -40 X .500 Button head socket cap screw                            | 2   |
| 23     | 85000003     | Hex Wrench for Reservoir Mounting Screws                             | 1   |



**WARNING: ATTEMPTING TO REMOVE THE AIR FITTING WILL DAMAGE IT AND VOID THE WARRANTY.**



### ShockWave Installation



1. Check the weld in the area pointed out. We have seen some very poor factory welds in this area. If it doesn't look adequate to support the vehicle, reweld the area.




2. Drill the OEM shock hole out to 3/4". This can be done with a Unibit. The Shockwave stud top will come in contact with the coil spring retainer, so it must be opened up towards the engine. A die grinder works well here.



3. Some trimming must also be done on the outside of the frame pocket to allow clearance for the Shockwave.




### ShockWave Installation



**4.** To allow clearance for the Shockwave, some trimming must be done on the inside of the coil spring pocket as shown by the white line in the picture. This is best done with either a cut off wheel or plasma cutter. Grind all cuts smooth when finished.

**Note:** It may be helpful to go ahead and install the lower StrongArms and Shockwaves to determine exactly what needs to be removed.



**Note:** The airline must also be routed at this time. It can be ran through the subframe toward the rear of the vehicle.

**5.** The air fitting location can be rotated by twisting the bellow assembly separate of the shock. Place the Shockwave into the coil spring pocket with the stud sticking through the OEM shock hole. See assembly **Diagram 4**. OEM Shock hole **must** be drilled out to  $\frac{3}{4}$ "




1. Stud top aluminum base
2. Delrin ball lower half
3. Delrin ball upper half
4. Aluminum cap
5. 9/16" SAE Nylok jam nut
6. Threaded stud (screwed onto shock shaft)
7. Rebound adjusting knob
8. Screw



**Part # 11162899**

**1967-1969 GM F-Body, 1968-74 GM X-Body Front Lower StrongArms**

### Recommended Tools



## 1967-1969 GM F-Body Lower StrongArms Installation Instructions

### Table of contents

Page 7..... Lower Control Arm Components  
Page 8..... Getting Started & Installation  
Page 9..... Installing Spindles and Steering Stop






### Lower Control Arm Components .....In the box

| Item # | Part Number | Description                                       | QTY |
|--------|-------------|---------------------------------------------------|-----|
| 1      | 90000621    | Driver Lower Control Arm <b>(Shown)</b>           | 1   |
| 1      | 90000622    | Passenger Lower Control Arm                       | 1   |
| 2      | 90000898    | Lower Ball Joint Assembly - Proforged # 101-10013 | 2   |
| 3      | 70010759    | Delrin Bushing - with 2" Diameter Ledge           | 8   |
| 4      | 90002062    | CoilOver Bearing Spacers                          | 4   |
| 5      | 90000516    | 1/2" ID Inner Sleeve                              | 4   |
| 6      | 99501005    | 1/2"-13 x 3 1/2" Hex Bolt                         | 6   |
| 7      | 99502009    | 1/2"-13 Nylok Nut                                 | 6   |
| 8      | 99503014    | 1/2" SAE Flat Washer                              | 12  |
| 9      | 99371005    | 3/8"-16 x 1 1/4" Hex Bolt                         | 2   |
| 10     | 99372012    | 3/8"-16 Hex Nut                                   | 2   |

Driver Side Shown






### Getting Started.....

Congratulations on your purchase of the Ridetech F-Body StrongArms. These StrongArms have been designed to give your F-Body excellent handling along with a lifetime of enjoyment. Some of the key features of the StrongArms: Ball joint angles have been optimized for the lowered ride height, Delrin bushings are used to eliminate bushing deflection along with providing free suspension movement through the entire travel. The Geometry has been optimized for excellent handling, and drive ability. The Delrin bushings are made from a material that is self lubricating so no grease zerks are needed.

**Note:** These control arms are designed for use with the Ridetech CoilOvers and the MuscleBar swaybar. **The factory shocks and springs or the factory sway bar will not fit these arms.**

### Installation


1. Remove the entire lower control arms from the car. If you are replacing the upper control arms and spindle, remove them too. Refer to a Factory Service Manual for the proper method.
2. Drill the factory upper shock mounting hole to 3/4". This can be done easily with a Unibit.



3. After removing the factory lower control arm, clean the bushing mounting surfaces on the frame. The Control Arms are marked "D" for Driver and "P" for Passenger. The Ballpoint Pin points up and the Sway bar mount is on the front side of the arm. Install a 1/2" flat washer on each of (2) 1/2"-13 x 3 1/2" bolts. Insert the bolt/washers through the mounting holes. Install a 1/2" flat washer and 1/2"-13 nylok nut. Torque to 75 ft-lbs.

**Note:** On some cars the frame brackets may be pinched and will need to be spread back apart to allow the bushing to slide in.

**Install the CoilOvers at this time. Refer to the CoilOver instructions for Assembly.**




4. Insert the Bearing Spacers into the lower shock bearing. The SMALL end goes into the bearing. Swing the Control Arm up, line up the 1/2" holes with the bearing spacers, insert 1/2"-13 x 3 1/2" bolt. Install a 1/2" flat washer and nylok nut. Torque to 75 ft-lbs. **Note:** The shock bolt will need to be installed from the rear with the threads pointing to the front of the car.



### Installing Spindle & Setting Steering Stop

5.



5. Attach the Spindle to the control arms.

#### Torque Specs:

Lower Ball joint - 65 ftlbs and tighten to line up cotter pin.

Install the Cotter Pin after tightening the ball joint nut.

6.



6. Thread the 3/8\"-16 nut onto the 3/8\"-16 x 1 1/4\" bolt. Thread it into the front hole of the ball joint plate. You will need to adjust the steering stop to suite your needs. This setting will vary depending on wheel and tire size and other suspension components. Torque to 12 ft-lbs.

**NOTE:** If you are running the TruTurn setup, this steering stop bolt will not be used.

7. Tighten all fasteners. If you are going to install the Ridetech MuscleBar, now is a good time to do it.

#### Suggested Alignment Specs:




|         |                                |
|---------|--------------------------------|
| Camber: | Street: -.5 degrees            |
| Caster: | Street: +3.0 to + 5.0 degrees  |
| Toe:    | Street: 1/16\" to 1/8\" toe in |



**Part # 11163699**

**1967-1969 GM F-Body, 1968-74 GM X-Body Front Upper StrongArms**

**Recommended Tools**



## **1967-1969 GM F-Body Upper StrongArms Installation Instructions**

### **Table of contents**

|              |                                      |
|--------------|--------------------------------------|
| Page 11..... | Upper Control Arm Components         |
| Page 12..... | Getting Started                      |
| Page 13..... | Caster Explained                     |
| Page 14..... | Offset Upper Control Arm Cross Shaft |
| Page 15..... | Installing Spindle and Alignment     |






### Upper Control Arm Components .....In the box

| Item # | Part Number  | Description                                              | QTY |
|--------|--------------|----------------------------------------------------------|-----|
| 1      | 90002390     | Driver Upper Control Arm <b>(Shown)</b>                  | 1   |
| 1      | 90002391     | Passenger Upper Control Arm                              | 1   |
| 2      | 90000908 kit | Upper Ball Joint Kit - Proforged # 101-10015             | 2   |
| 3      | 90000914 kit | Caster Slug Cross Shaft Kit                              | 2   |
| 4      | 70010883     | Caster Slug                                              | 4   |
| 5      | 70010759     | Outer Delrin Bushing with 2" Lip                         | 4   |
| 6      | 70010827     | Inner Delrin Bushing with 1.75" Lip                      | 2   |
| 7      | 70010826     | Inner Delrin Bushing with No Lip                         | 2   |
| 8      | 90002737     | Aluminum T-Washer                                        | 4   |
| 9      | 70001323     | Bumpstop                                                 | 2   |
| 10     | 99373003     | 3/8" SAE Flat Washer - Bumpstop                          | 2   |
| 11     | 99372002     | 3/8"-16 Nylok Nut - Bumpstop                             | 2   |
| 12     | 99622005     | 5/8"-18 Jam Lock Nut - Included with 90000914 kit        | 4   |
|        | 99433004     | 7/16" USS Flat Washer - Control Arm Mounting - NOT SHOWN | 4   |

### Driver Side Shown






### Getting Started.....

Congratulations on your purchase of the Ridetech F-Body StrongArms. These StrongArms have been designed to give your F-Body excellent handling along with a lifetime of enjoyment. Some of the key features of the StrongArms: Ball Joint angles have been optimized for the lowered ride height, Delrin bushings are used to eliminate bushing deflection along with providing free suspension movement through the entire travel. The Geometry has been optimized for excellent handling and driveability. The Delrin bushings are made from a material that is self lubricating so no grease zerks are needed.


**When assembling the Control Arms tighten the cross shaft nuts enough to create drag on the delrin bushings, the arm should still move through its travel by hand.**

### Installation

1. Remove the entire upper control arms from the car. If you are replacing the lower control arms and spindle, remove them too. Refer to a Factory Service Manual for the proper method.




2. The Upper Control Arm is attaching the factory mount using factory hardware. The driver side arm is shown in **Figure "2"**. The Ball Joint located on the arm to the rear of the car. Install the T-Washers and 5/8"-18 Lock Nuts using **Figure "2"** as a reference. These can be tightened after installing the control arms on the car.



3. Install the Ball Joints in the control arms using **Figure "3"** as a reference. Torque the hardware to 15 ftlbs



### Caster Explained



These StrongArms come equipped with a changeable caster slug setup. This allows you to add or remove caster from the front suspension, if desired. The caster slugs that come supplied in the kit are setup to be centered. The caster slugs allow you to add or remove caster without having to use a stack of shims. If more or less caster is desired, optional slugs can be purchased from Ridetech or your Ridetech dealer.

1/8" = 70010882

1/4" = 70010881

### Caster Explained:


To understand caster you need to picture an imaginary line that runs through the upper balljoint and extends through the lower balljoint. From the side view the imaginary line will tilt forward or backward. The tilting of this imaginary line is defined as caster.

Caster is measured in degrees by using a caster gauge. If the imaginary line described above tilts towards the back of the vehicle at the top, then you have positive caster. If the imaginary line tilts forward then you have negative caster.

Positive caster provides the directional stability in your vehicle. Too much positive caster will make the steering effort difficult. Power steering will allow you to run more positive caster. Negative caster requires less steering effort but will cause the vehicle to wander down the highway.



### Offset Upper Control Arm Shaft



The cross shaft that is used in the upper control arms is offset. The offset combined with the caster slug option allows you to achieve the alignment setting you desire with minimal shims. To change the direction the Icon faces simply spin the cross shaft in the control arm.

If you are after a **Street Alignment** bolt the upper control arm to the frame mount with the arm offset to the outside of the car. The Ridetech Icon and Caster Slugs will be facing the wheel.


If a more aggressive **Track or Autocross** alignment is desired, bolt the control arm to the frame bracket with the arm offset to the inside of the car. The Ridetech Icon and Caster Slugs will be facing the engine.



### Installing Spindle and Alignment



4. The Upper Control Arm is attaching the factory mount using factory hardware with the supplied 7/16" Flat Washer under the OEM Nut. Torque the nuts to 50 ft-lbs. The driver side arm is shown in **Figure "2"**. The Arrow on the Cross shaft points to the front of the car. **Page 4 & 5** has information about Caster and the Caster Slugs.



5. Attach the Spindle to the control arms.

#### Torque Specs:

Upper Ball Joint - 50 ftlbs and tighten to line up cotter pin.

Install the Cotter Pin after tightening the ball joint nut.

6. Tighten all fasteners.

**When assembling the Control Arms tighten the cross shaft nuts enough to create drag on the delrin bushings, the arm should still move through its travel by hand.**




#### Suggested Alignment Specs:

|         |                               |
|---------|-------------------------------|
| Camber: | Street: -.5 degrees           |
| Caster: | Street: +3.0 to + 5.0 degrees |
| Toe:    | Street: 1/16" to 1/8" toe in  |



### Part # 11009303 - A/F/X Tall Spindle Kit

#### Recommended Tools



#### A/F/X Tall Spindle Kit

## Installation Instructions

#### Table of contents

|                 |                                  |
|-----------------|----------------------------------|
| Page 17.....    | Included Components and Hardware |
| Page 17.....    | Getting Started and Installation |
| Page 17-18..... | Installation                     |
| Page 18.....    | The Finish                       |

THIS SPINDLE IS DESIGNED TO FIT 64-72 GM A-BODY, 67-69 GM F-BODY, AND 68-74 GM X-BODY. THESE SPINDLES ARE SYMMETRICAL, THEY AREN'T SIDE SPECIFIC UNTIL THE STEERING ARM IS BOLTED ON.

**THESE SPINDLES ARE A DIRECT REPLACEMENT FOR OEM DISC BRAKE SPINDLES. IF YOUR CAR HAS DRUM BRAKES, YOU WILL HAVE TO CONVERT IT TO DISC BRAKES. THEY WILL ACCEPT ANY BRAKE KIT THAT IS DESIGNED FOR THE OEM DISC BRAKES SPINDLES.**



### Major Components .....In the box

| Part #   | Description             | QTY    |
|----------|-------------------------|--------|
| 11009304 | Spindles (Pair)         | 1 pair |
| 90002743 | 3/4"-20 Spindle Nut Kit | 1 kit  |

| Part #                         | Description               | QTY |
|--------------------------------|---------------------------|-----|
| <b>Hardware KIT # 99010174</b> |                           |     |
| 99621001                       | 5/8"-18 X 1" BOLT         | 2   |
| 99501071                       | 1/2"-20 x 3" FSCS         | 4   |
| 99501054                       | 1/2"-20 x 2 1/2" FSCS     | 2   |
| 99502002                       | 1/2"-20 Nylok Nut         | 6   |
| 99502005                       | 1/2"-20 x 2" Bolt         | 2   |
| 99952003                       | 1/8" x 1 1/2" Cotter Pins | 4   |

### Getting Started.....

These spindles will fit '67-69 Camaro, '64-'72 Chevelle, and '68-'74 Nova. They will provide a 2" drop, and are taller than stock to improve the car's cornering ability. The raised upper ball joint induces negative camber gain and positive caster gain. This helps keep the tires flat on the pavement when cornering. This camber action change also raises the roll center for less body roll, and transfer the car's center of gravity inboard in the turn as well. You will see an appreciable improvement in handling.

These spindles are designed around stock disc brake spindles and will accept any disc brake set up designed for those. **The only modification we discovered to be necessary, was a small trim on the bottom of the stamped 1/4" steel caliper bracket that holds the caliper.** It is an area that is not stressed and will not cause any loss of strength. Trim only enough to make the caliper bracket clear the spindle. If you are using the factory dust shields, they will also require trimming. If your car came with drum brakes, be sure to swap to the appropriate disc brake master cylinder and valving.

### Installation

1.



**IF YOU HAVEN'T ALREADY DONE SO, REMOVE THE OEM SPINDLE. IF REUSING THE EXISTING CALIPERS, BE SURE TO SUPPORT THEM TO KEEP FROM PUTTING UNWANTED STRESS ON THE BRAKE LINES.**

1. The steering arm will bolt to the BOTTOM set of holes in the Ridetech spindle using the supplied 1/2" hardware. The mounting bosses of the steering arm are 2 different thicknesses. The uses a 1/2"-20 x 3" flat socket cap screw. The thin boss will use a 1/2"-20 x 2 1/2" flat socket cap screw.



### Installation



**NOTE:** Some steering arms have 7/16" mounting holes, they will need to be drilled out using a 1/2" drill bit.

**2.** Line up the steering arm mounting holes with the bottom 2 holes of the spindle. Insert the 3" long bolt through the thick boss and the 2 1/2" long bolt through the thin boss, inserting the bolts from the front of the spindle. Slip the steering arm onto the bolts. Install a 1/2"-20 nylok nut on each bolt. The steering arm hardware will need to be torqued to 100 ftlbs, but it is easier to torque with the spindle installed on the car.

### The Finish

**3.** Attach the spindles to the control arms. Torque the ball joints and tie rods end using the torque specs below.

#### Torque Specs:

|                    |                                             |
|--------------------|---------------------------------------------|
| Lower Ball Joint - | 65 ftlbs and tighten to line up cotter pin. |
| Upper Ball Joint - | 50 ftlbs and tighten to line up cotter pin. |
| Tie Rod End -      | 35 ftlbs and tighten to line up cotter pin. |

#### Wheel Bearing Tightening:

While turning the rotor, tighten the nut to 12 ftlbs with a torque wrench. Back off the nut one flat and insert the cotter pin. If the slot and pin hole don't line up, back off the nut an additional half flat or less as required to insert the pin. Note: Bearings should have zero preload and .001" to .008" of end movement. Bend the ends of the cotter pin, replace the dust cap. On a disc brake with the caliper removed, it's normal to have a slight amount of play detectable in the bearing.

**5.** Recheck all hardware before driving.

**6. PUMP THE BRAKE PEDAL BEFORE DRIVING TO RESET THE BRAKE PADS TO THE ROTOR. IF YOU HAD THE CALIPERS REMOVED, BLEED THE BRAKE SYSTEM.**

#### Suggested Alignment Specs:



|         |                               |
|---------|-------------------------------|
| Camber: | Street: -.5 degrees           |
| Caster: | Street: +3.0 to + 5.0 degrees |
| Toe:    | Street: 1/16" to 1/8" toe in  |



### Part # 11169120 - 1967-1969 GM F-Body Front Sway Bar



#### Recommended Tools



## 1967-1969 GM F-Body Front Sway Bar Installation Instructions

#### Table of contents

Page 20..... Included Components and Hardware List  
Page 20-21.... Sway Bar Installation

#### Hardware Torque Specifications

5/16"-16..... 17 ftlbs

[www.ridetech.com](http://www.ridetech.com)



REV2 4/6/22

## Major Components .....In the box

| Part #          | Description             | QTY |
|-----------------|-------------------------|-----|
| 90001234        | Front Sway Bar          | 1   |
| 90002929        | End Link Kit            | 1   |
| 90002572        | Bushing Strap           | 2   |
| 70015013        | Lined Sway Bar Bushing  | 2   |
| <b>HARDWARE</b> |                         |     |
| 99311030        | 5/16" -18 x 1" Hex Bolt | 4   |
| 99313001        | 5/16" SAE Flat Washer   | 4   |
| 99313005        | 5/16" Split Lock Washer | 4   |


## Getting Started.....

**Note:** This sway bar kit utilizes a anti-friction lining in the sway bar bushing. The lining allows the sway bar to move freely and quietly in the bushing. No lubrication is required.

1. Jack the vehicle up to a safe working height and support with jack stands. Make sure the jack stands are stable before working under the car.
2. Remove the driver front wheel/tires. It will be required to get the swaybar installed
3. Remove the stock sway bar.



4. Open the sway bar bushing at the split and slip it **OVER** the sway bar. Do this for both bushings




5. Insert the sway bar in the stock location. See below for installation tips.

**Installation Tips:** It is easier to install if you have the driver wheel/tire removed. Turning the steering wheel to the left also helps. It will require some twisting and turning of the bar to work it through the frame into the stock location. The swaybar needs to end up in the stock location with the ends above the lower control arms.



**6.**

**6.** Slip the bushing straps over the sway bar bushings. Line them up with the OEM mounting holes.




**8.**

**7.** Install a 5/16" lock washer & 5/16" flat washer on the 5/16"x 1" hex bolts.




**8.**

**8.** Torque the mounting hardware to 17 ftlbs.




**9.**

**9.** Install the end links using **Diagram 1** as a reference. Install both end links before tightening the end link hardware. Tighten the end link barrel nut until it is flush with the end of the bolt, and then tighten it 2 more complete rounds.







### Part # 11267159 -1973-1974 GM "X" Body Rear R-Joint Bolt-in 4 Link



#### Recommended Tools



## 1973-1974 GM "X" Body Rear Bolt-in 4Link Installation Instructions

#### Table of contents

|                 |                                         |
|-----------------|-----------------------------------------|
| Page 23-24..... | Included Components                     |
| Page 25.....    | Hardware List & Getting Started         |
| Page 26.....    | OEM Variation                           |
| Page 26-31..... | Cradle Installation                     |
| Page 31.....    | Lower Bar Installation                  |
| Page 32.....    | Lower Bar & Shock Mount Installation    |
| Page 33.....    | Attaching Lower Shock Mount & Lower Bar |
| Page 34.....    | Installing Lower Bar                    |
| Page 35.....    | Setting Pinion Angle                    |
| Page 36.....    | Upper Bar Axle Tab Installation         |
| Page 37.....    | Installing Axle Tabs                    |
| Page 38.....    | Installing ShockWaves/CoilOvers         |






### Major Components .....In the box

| Item #                                              | Part #   | Description                                            | QTY |
|-----------------------------------------------------|----------|--------------------------------------------------------|-----|
| 1                                                   | 90003365 | Upper Cradle                                           | 1   |
| 2                                                   | 90003367 | Forward Tab Inner Brace                                | 2   |
| 3                                                   | 90003347 | Lower Axle Mount - Driver                              | 1   |
| 4                                                   | 90003348 | Lower Axle Mount - Passenger                           | 1   |
| 5                                                   | 90002819 | Lower Bar Assembly - Driver - 25 /16" center to center | 2   |
| 6                                                   | 70013537 | Front R-Joint Spacer                                   | 2   |
| 7                                                   | 90001318 | RH R-Joint Threaded Housing End (installed in bars)    | 2   |
| 8                                                   | 90003370 | Upper Bar - 9.00" center to center set length          | 2   |
| 9                                                   | 70013334 | R-Joint Spacers                                        | 14  |
| 10                                                  | 70013049 | Inner Upper Bar Tab - Driver                           | 1   |
| 11                                                  | 70013050 | Inner Upper Bar Tab - Passenger                        | 1   |
| 12                                                  | 70013051 | Outer Upper Bar Tab                                    | 2   |
| 13                                                  | 70013052 | Axle Tab Rear Brace                                    | 2   |
| 14                                                  | 90001624 | Aluminum Lower Shock Mount                             | 2   |
| 15                                                  | 70002825 | Lower Shock Stud                                       | 2   |
| 16                                                  | 90002067 | Lower Shock Spacers                                    | 4   |
| 17                                                  | 99752004 | RH 3/4"-16 Jam Nut (installed on bar ends)             | 2   |
| 18                                                  | 90002285 | Square U-Bolt                                          | 4   |
|                                                     | 85000008 | Riv-Nut Installation Tool (NOT SHOWN)                  | 1   |
|                                                     | 70010694 | Bar Tab Setting Jig (NOT SHOWN)                        | 2   |
|                                                     | 99371050 | 3/8"-16 x 1 1/2" Conical Body Bolt (NOT SHOWN)         | 6   |
|                                                     | 99372009 | 3/8"-16 U-Nut (NOT SHOWN)                              | 6   |
| <b>R-Joint Components - (Installed in bar ends)</b> |          |                                                        |     |
|                                                     | 70013279 | Retaining Ring                                         | 6   |
|                                                     | 70013280 | Wavo Wave Spring                                       | 6   |
|                                                     | 70013275 | R-Joint Center Ball                                    | 6   |
|                                                     | 70013276 | R-Joint Composite Center Ball Cage                     | 6   |

New R-Joints will be quite stiff (75-90 in/lbs breakaway torque) until they "break in" after a few miles of use. After the break in period they will move much more freely. Because the composite bearing race contains self lubricating ingredients, no additional lubrication is needed or desired. Any additional lubrication will only serve to attract more dirt and debris to the R-Joint and actually shorten its life.




### Major Components .....In the box




#### R-JOINT SPACER INSTALLATION

Install the Spacers by inserting the SMALL side of the SPACER into the Center Pivot Ball. Push them in until they bottom out and stop.

#### LOWER FRONT R-JOINT



#### ALL OTHER R-JOINTS



New R-Joints will be quite stiff (75-90 in/lbs breakaway torque) until they "break in" after a few miles of use. After the break in period they will move much more freely. Because the composite bearing race contains self lubricating ingredients, no additional lubrication is needed or desired. Any additional lubrication will only serve to attract more dirt and debris to the R-Joint and actually shorten its life.



### Hardware List .....In the box (Kit# 99010211)

The Hardware Kit contains bags to help aid in selecting the correct hardware for the component being installed. The hardware list shows how the hardware is bagged.

| Item #                         | QTY | Part Number | Description               | Item #                                  | QTY | Part Number | Description                |
|--------------------------------|-----|-------------|---------------------------|-----------------------------------------|-----|-------------|----------------------------|
| <b>CRADLE TO FLOOR</b>         |     |             |                           | <b>LOWER BAR - FRONT MOUNTING</b>       |     |             |                            |
| 19                             | 4   | 99371007    | 3/8"-16 x 1 1/2" Hex Bolt | 28                                      | 2   | 99621007    | 5/8"-18 x 5" Hex Bolt      |
| 20                             | 4   | 99372001    | 3/8-16" Nylok Nut         | 29                                      | 2   | 99622006    | 5/8"-18 Nylok Jam Nut      |
| 21                             | 8   | 99373002    | 3/8" SAE Flat Washer      | 30                                      | 4   | 99623001    | 5/8" Flat Washer           |
| <b>SQUARE U-BOLTS</b>          |     |             |                           | <b>4 LINK BARS</b>                      |     |             |                            |
| 20                             | 8   | 99372001    | 3/8-16" Nylok Nut         | 29                                      | 6   | 99622006    | 5/8"-18 Nylok Jam Nut      |
| 21                             | 8   | 99373002    | 3/8" SAE Flat Washer      | 30                                      | 12  | 99623010    | 5/8" SAE Flat Washer       |
| <b>CRADLE TO FRAME</b>         |     |             |                           | 31                                      | 6   | 99621004    | 5/8"-18 x 3" Gr. 8 Bolt    |
| 21                             | 10  | 99373002    | 3/8" SAE Flat Washer      | <b>SHOCK TO CRADLE</b>                  |     |             |                            |
| 22                             | 10  | 99371005    | 3/8"-16 x 1 1/4" Bolt     | 32                                      | 2   | 99501026    | 1/2"-13 x 2 1/4" Hex Bolt  |
| 23                             | 10  | 99372007    | 3/8"-16 Riv-Nut           | 33                                      | 2   | 99502007    | 1/2"-13 Thin Nylok Jam Nut |
|                                | 1   | 85000007    | 17/32" Drill Bit          | 34                                      | 4   | 99503014    | 1/2" SAE Flat Washer       |
| <b>SHOCK STUD</b>              |     |             |                           | <b>SHOCK MOUNT &amp; SHOCK MOUNTING</b> |     |             |                            |
| 24                             | 2   | 99432002    | 7/16"-20 Nylok Nut        | 35                                      | 2   | 99501019    | 1/2"-13 x 1 1/4" Hex Bolt  |
| 25                             | 2   | 99433002    | 7/16" SAE Flat Washer     | 36                                      | 2   | 99501046    | 1/2"-13 x 1 3/4" Hex Bolt  |
| 26                             | 2   | 99623004    | 5/8" SAE Flat Washer      | 37                                      | 4   | 99502001    | 1/2"-13 Nylok Nut          |
| <b>LOWER BAR MOUNT TO AXLE</b> |     |             |                           | <b>UPPER 4 LINK TAB SETTING JIG</b>     |     |             |                            |
| 27                             | 8   | 99432007    | 7/16"-20 Nylok Nut        | 38                                      | 2   | 99371001    | 3/8"-16 x 3/4" Hex Bolt    |
|                                |     |             |                           | 39                                      | 2   | 99372004    | 3/8"-16 Hex Nut            |

### Getting Started.....

Congratulations on your purchase of the Ridetech Rear 4-link System. This system has been designed to give your X-Body excellent handling along with a lifetime of enjoyment. This kit replaces the Leaf Springs, this allows the 4-Link to locate the rear end and the CoilOvers/ShockWaves to support the car. This allows each to be optimized for the best performance.

**Note:** These system is designed for use with the Ridetech Shockwaves or CoilOvers. **The factory shocks and springs will not fit this setup.**

1. Raise the vehicle to a safe and comfortable working height. Use jack stands to support the vehicle with the suspension hanging freely. You will need a method of raising and lowering the differential.
2. Support the axle and remove the leaf springs, shocks, pinion snubber, and tail pipes. Refer to the factory service manual for proper disassembly procedures. Retain the front leaf spring mounts, they will be used with the 4 link. You may need to detach the fuel line from the frame rails. The back seat of the car will also need removed for installation of the 4 link cradle.




### 73-74 Frame Rail Variations



1973 & 1974 can have 2 different rear frame rail variations. If your frame rail has a hump similar to the one circled in the left image, you have the correct kit. If your frame rail is flat and doesn't have the hump, you need kit # 11267199. Please contact customer service if you have the incorrect kit.

### OEM Variation



**Note:** In rare cases, the dimension from frame rail to frame rail on your X-Body may vary from the dimension on the Ridetech Upper Cradle. **ALL** of the Ridetech Upper Cradles are jig built to the dimensions above. The variation in OEM manufacturing specs does happen and is out of our control. If your X-Body frame rails seem out of spec, feel free to contact our Tech Department at 812-482-2932 and we will try to offer some solutions.

### Cradle Installation



**3.** Remove the factory pinion snubber from the car by removing the (2) retaining bolts.



### Cradle Installation



**4. Steps 5-17 cover mounting the cradle into the car, review all steps.** Lower the axle enough to slide the upper cradle into place. Install the cradle into the car. When the cradle is positioned properly, the front bar should be up against the body and the front tab will be up against the bottom side of the seam. **Image 4 shows the cradle installed in the car.**

**Note:** The OEM fuel line may need to be detached from the frame rails until the cradle is installed.



**5.** Install the cradle into the car. When the cradle is positioned properly, the front bar should be up against the body, the front tab will be up against the bottom side of the seam.

**THE CRADLE WILL GET TEMPORARILY BOLTED IN BY THE FRONT TAB AND LOWER FRAME RAIL U-BOLTS. IT WILL GET REMOVED TO DRILL AND INSTALL THE RIV-NUTS IN THE FRAME RAILS.**



**6. Images 5 & 6** shows how the front tab overlaps the body seam. Multiple pieces of the car body overlap at this joint making it a strong area to attach to. **We recommend removing the back seat before drilling these holes.** Drill these 4 holes with a 3/8" drill bit using the cradle as a template.



### Cradle Installation



**7.** The kit includes (2) backing plates for the front tab. These backing plates are installed in the inside of the car. The rear seat should have already been removed before the holes were drilled. Lay the backing plates on the seam, lining up the 2 holes drilled in the previous step. Install a 3/8" flat washer on each of (2) 3/8"-16 x 1 1/4" hex bolts.



**8.** Do this for both backing plates. There should be a plate on each side of the drive shaft tunnel.



**9.** Install a 3/8" flat washer followed by a 3/8"-16 nylok nut on threads of each of the bolts sticking through the front tab. Tighten the hardware, but you don't need to torque the hardware at this time.



### Cradle Installation



**10.** Use the frame plates as a template to drill the holes in the bottom of the frame rails. Use a 7/16" drill bit to drill the holes. Drill the hole in the center of the slots.



**11.** Feed one end of the u-bolt through the round hole of the pair of holes, using the other end of the u-bolt as a handle. You need to get the end of the u-bolt that you are using as a handle fed in until it is past the 90 degree bend to be able to drop the other end through the drilled hole. If the u-bolt will not line up with the drilled holes, it may be necessary to slot the frame hole in the slotted hole of the frame mount.



**12.** Install (1) 3/8" Flat washer and (1) 3/8"-16 nylok nut onto each stud sticking through the cradle. Do not tighten them until all Washers and Nuts are installed. Tighten each leg of the u-bolt evenly, but you don't need to torque the hardware at this time.



### Cradle Installation



**13.** Mark the center of the (5) holes in each side plate. You can use a marker or a center punch. We used a 7/16" drill bit in a drill to mark the center of the holes. After marking the holes remove the cradle to install the riv-nuts.



**14.** Remove the cradle to drill the holes and install the Riv-nuts. The holes for the Riv-nuts NEED to be drilled with the supplied 17/32" drill bit. We suggest drilling the holes with a smaller drill bit first to make it easier to drill with the 17/32" drill bit. Drill all (10) holes in the frame rails.



**15.** Install the Riv-nuts in the sides of the frame rails. **Refer to the Riv-nut installation instructions on PAGE 10 for proper Riv-nut installation.** Image 15 illustrates a Riv-nut being installed. Install all (16) Riv-nuts in the frame rails.



### Riv-nut® Installation & Specs

**1.** Drill hole in frame using the SUPPLIED DRILL BIT keeping the drill square with the metal.

**2.** We recommend installing (2) 3/8" flat washers between the bolt head and the lower anvil of the installation tool. Thread a Riv-nut® onto the supplied Tool. Thread the Riv-nut all the way onto the tool until it stops.

**3.** Insert the tool and Riv-nut® into the drilled hole 90° to the frame rail.

**4.** The tool requires (1) 9/16" & (1) 5/8" wrenches to use. A ratchet can be used on the top of the tool.

**KEEP THE TOOL AND RIV-NUT 90° TO THE SURFACE WHILE TIGHTENING**

**5.** Put a 5/8" wrench on the lower hex of the tool. Use a wrench or ratchet on the top hex to tighten.

**6.** Hold the wrench in one position and turn the TOP HEX CLOCKWISE to engage the Riv-nut®. Keep turning the TOP WRENCH until you feel a positive stop and you can't turn the TOP WRENCH anymore.


**7.** Break the tool loose by turning the TOP HEX counterclockwise and thread the tool out of the Riv-nut®

**THE DATA BELOW ILLUSTRATES THE STRENGTH OF THE RIV-NUT®**

#### RIVNUT® Fastener Engineering Data


| Upset Load (lbs.) |           |           |
|-------------------|-----------|-----------|
| RIVNUT * Size     | Steel     |           |
|                   | Min. Grip | Max. Grip |
| 3/8-16            | 4965      | 5325      |

Fig. 1




| Ultimate thread strength (lbs.) |           |           |
|---------------------------------|-----------|-----------|
| RIVNUT * Size                   | Steel     |           |
|                                 | Min. Grip | Max. Grip |
| 3/8-16                          | 11500     | 10450     |

Fig.2



| Ultimate tensile strength (lbs.) |       |
|----------------------------------|-------|
| RIVNUT * Size                    | Steel |
| 3/8-16                           | 3900  |

Fig. 3



**Single Shear Strength 3/8" Grade 5 Bolt  
3,975.8 lbs**




Figure 2




Figure 3




Figure 6



### Cradle Installation & Lower Bar



**16.** After you get all the riv-nuts installed, reinstall the cradle in the car. The bolts for the front tab can be reinstalled. Also, reinstall the u-bolt hardware. Leave everything loose until all the bolts are started.



**17.** Install a 3/8" split lock washer & 3/8" flat washer on each of the 3/8"-16 x 1 1/4" bolts supplied in the kit. Thread them into the riv-nuts. Torque to 23 ft-lbs. Torque the front tab and u-bolt hardware to 30 ft-lbs.



**18.** The R-joint setup is designed to be offset to the inside of the car. The bolt hole in the mounting bracket has to be drilled out to 5/8" and the new 5/8" x 5" bolt, washers, & 5/8" thin nylok nut are used. The wider spacer is used on the outside with a narrow spacer on the inside. This will offset the bar to the inside of the car for better wheel and tire clearance. The bolt needs to go in the bracket like seen in the picture. The threads of the bolt must be pointing to the OUTSIDE of the car. Shown in **Image 18** is the driver side bar and mount. Repeat on both sides and tighten the bolts/nuts enough to eliminate any gaps.



### Lower Bar & Shock Mount Installation




**19.** Attach the lower bar/mount assembly to the car. New 3/18"-16 u-nuts and 3/8-16" x 1 1/2" conical body Bolts are supplied in the kit. Install the u-nuts in place of the OEM u-nuts. Hold the assembly in place lining up the holes with the u-nuts. There is a tab bent up on the mount that indexes into a hole in the body. Make sure the tab is indexed into the alignment hole. Torque the mounting bolts to 30 ft-lbs.



**20.** The lower axle bracket will be fastened to the leaf spring pad using the factory T-bolts/ U-bolts. The bar mount is offset to the inside of the car to provide more wheel and tire clearance. New 7/16" nyloks are supplied. Torque the nuts to 55 ftlbs.


**Image 20** shows the Driver side.

The 68-74 X-body could come with either a **Monoleaf spring** or **Multileaf spring**. We provided this guide to help you determine which leaf spring mount your car has. **Steps 21 & 22** cover bolting the lower shock mount to the axle bracket. You need to know which leaf spring mounts you have to determine how the shock mount needs bolted to the axle mount. **Image 21** shows the Multileaf, **Image 22** covers the Monoleaf. The leaf spring mount on each of the rear differentials are different heights requiring the lower shock mount be attached in different locations depending on the leaf spring mount. The lower mount attaches with (1) 1/2"-13 x 1 1/4" hex bolt, (1) 1/2"-13 x 1 3/4" Hex Bolt, & (2) 1/2"-13 nylok nut.







### Attaching Lower Shock Mount & Lower Bar



**21. MULTILEAF** - The Multileaf setup uses the **MIDDLE 2 HOLES** for mounting. Insert the bolts through the aluminum shock mount with the 1 1/4" long bolt in the top bolt, 1 3/4" in the bottom hole. Insert the bolts through the axle mount and install the nylok nuts on the threads sticking through. Repeat on both sides and torque the bolts/nuts to 75 ftlbs. Skip to **Step 23**.




**22. MONOLEAF** - The Monoleaf setup uses the **BOTTOM 2 HOLES** for mounting. Insert the bolts through the aluminum shock mount with the 1 1/4" long bolt in the top bolt, 1 3/4" in the bottom hole. Insert the bolts through the axle mount and install the nylok nuts on the threads sticking through. Repeat on both sides and torque the bolts/nuts to 75 ftlbs.




**23.** Installing the shock stud into the lower mount. Install a 5/8" flat washer onto the 5/8"-18 threads of the shock stud. Apply Red Loctite to the 5/8" threads of the stud. Thread the shock stud into the threaded hole of the lower mount. Repeat on both sides and torque the shock stud to 65-75 ftlbs.



### Installing Lower Bar



**24. Images 24-26** illustrate attaching the lower bar to the axle mount. Image 24 shows the Multileaf, Image 25 covers the Monoleaf, Image 26 shows a bottom view. The different heights of the leaf spring pads of the differentials require the lower bars to be mounted in the correct hole to optimize the geometry of the 4 link bars. A 70013334 spacer will need to be installed on each side of the R-Joint with the SMALL OD inserted into the R-joint center ball. Use **Image 26** as a reference. The lower bar attaches with (1) 5/8"-18 x 3" hex bolt, (2) 5/8" flat washers, & (1) 5/8"-18 nylok jam nut. **MULTILEAF** - The Multileaf setup uses the MIDDLE HOLES for mounting. Insert the bar into the lower mount lining the bushing sleeve up with the CENTER set of holes. Insert a 5/8"-18 x 3" bolt into the hole/sleeve. Install a 5/8"-18 nylok jam nut on the bolt threads sticking out of the bracket. Repeat on both sides and tighten the bolts/nuts enough to eliminate any gaps. Skip to **Step 23**.



**25. MONOLEAF** - The Monoleaf setup uses the BOTTOM HOLES for mounting. Insert the bar into the lower mount lining the bushing Sleeve up with the BOTTOM set of holes. Insert a 5/8"-18 x 3" bolt into the hole/sleeve. Install a 5/8"-18 nylok jam nut on the bolt threads sticking out of the bracket. Repeat on both sides and tighten the bolts/nuts enough to eliminate any gaps.



**26. Image 26** shows a bottom view of the bar installed. Notice the spacers in each side of the R-Joint.



### Setting Pinion Angle


**READ PAGES 16-18 ON SETTING RIDE HEIGHT, SETTING PINION ANGLES & UPPER BAR TAB JIG INSTALLATION .**

How do you set the pinion angle? On a single-piece shaft you want to set it up where a line drawn through the center of the engine crankshaft or output shaft of the transmission and a line drawn through the center of the pinion are parallel to each other but not the same line.


Your transmission angle should be around 3 degrees down in the rear. If it is more or less than 3 degrees, you might want to consider changing it. Too little angle on the transmission reduces the amount of oil getting to the rear bushing. Too much transmission angle will increase the working angles of the u-joints which will increase the wear. With the transmission at 3 degrees down in the rear, you will want to set the pinion 3 degrees up in the front.

A simple way to do this is to place a digital angle finder or dial level on the front face of the lower engine pulley or harmonic balancer. This will give you a reading that is 90 degrees to the crank or output shaft unless you have real problems with your balancer. At the other end, you can place the same level or angle finder against the front face of the pinion yoke that is also at 90 degrees to the center line. If you rotate the yoke up or down so both angles match, you have perfect alignment.


Road testing will tell you if you have it right. If you accelerate and you get or increase a vibration, then the pinion yoke is too HIGH. Rotate it downward in small increments of a degree or two until the problem goes away. If you get or increase a vibration when decelerating, then the pinion yoke is too LOW. Rotate it upward to correct it.



Pinion nose down



Parallel centerlines  
Correct pinion angle





Pinion nose up



### Upper Bar Tab Installation Jig

#### Upper Bar Installation Jig

- This jig has been supplied to aid in the installation of the upper 4 link bar. It can be temporarily used to properly align, locate and weld the tabs onto the axle. It will also ensure that the mounting bolts are parallel to the ground.
- Follow the diagram below to set the jig to the same length as the upper bar, use the 3/8" x 3/4" bolt and nuts to set the length.
- Position the axle at ride height. Center the axle left to right between the quarter panels. Set pinion angle.
- Bolt one end of the jig to the cradle using a 5/8" x 3" bolt.
- Using another 5/8" x 3" bolt, fasten the axle tabs to the other end. There is a Driver and Passenger Inner Tab. It is bent to keep the tab from hitting the center section of the rear end. It is positioned with the tab bent to the front of the car. The short tab goes to the outside of the car. The tabs must be bolted to the outside of the jig.
- Swing the bar down letting the tabs rest onto the axle. Trim the brackets as necessary to minimize the gap to be welded.
- Check pinion angle, ride height and axle center. Tack-weld the tabs in place and tack-weld the back brace in place. Refer to Images 28 & 29 for position of the back brace.
- Remove jig and install upper bar.
- Repeat this process for the other side.
- Recheck pinion angle, ride height and axle center. (Sound familiar?)
- After the tabs have been tack welded on both sides, remove the upper bars to avoid damaging the rod end. Let the axle drop down for better access to the tabs. Lay 1" welds on the inside and outside of the tabs. Skip around from one side to the other to avoid overheating the tube.



| Item# | Description         |
|-------|---------------------|
| 1     | Upper Bar           |
| 2     | 3/4"-16 Jam Nut     |
| 3     | R-Joint End         |
| 4     | Alignment Jig       |
| 5     | Aluminum Spacer     |
| 6     | 5/8" x 2 3/4" Bolt  |
| 7     | 3/8"-16 Nut         |
| 8     | 3/8"-16 x 3/4" Bolt |




### Installing Axle Tabs




**27.** One helpful trick to help maintain ride height and pinion angle while adjusting is to tack weld a spacer between the axle and the outside of the frame as shown in the picture. This spacer should be 3 3/4" tall giving the Shockwave an eye-to-eye measurement of approximately 14 1/2". When measuring the axle center you can measure off of the frame rails. We also use a plum bob off the quarter panels to double check the axle center. Refer to **Page 15** on setting the pinion angle.

**Note:** You can tack weld the spacer in place after you get the pinion angle, and axle center set. This will ensure that nothing moves through the upper tab Installation.



**28.** Check the length of the upper bar; it should be 9.000" center to center. Bolt the axle tabs to the setting jig as specified on the previous page. Straight tab to the outside of the car, bent tab to the inside of the car. The bend needs to be to the front, making the front of the tab run parallel with the cast center section. If they are installed on the incorrect sides, the tab will hit the center section of the axle. Next, place the other end into the cradle. Both ends use a 5/8" x 3" and should not be fully tightened yet. For now just let axle tabs sit on the axle.



**29.** Check the fitment of the tabs and tack weld them to the axle. Do this for the Driver and Passenger side bars. Insert the bars into the cradle and tabs to double check fitment. Recheck axle center and pinion angle. Once satisfied with fitment weld the upper bar tabs onto the axle. Weld 1" at a time, skip around from one side to the other, and one tab to the other to avoid overheating the axle tube. When the tabs cool down, install the upper bars using (1) 5/8" x 3" bolt, (2) 5/8" flat washers, and (1) 5/8" Thin nylok nut on each end. Install a 70013334 spacer in each side of the R-joint using **Image 29** as a reference. Repeat on both sides and tighten the bolts/nuts enough to eliminate any gaps.



### Installing Shockwaves/Coilovers



#### Remove the Spacer from between the Axle and Frame.

**30.** Insert a 1/2" ID 90002043 spacer into each side of the ShockWave/CoilOver bearing. Install a 1/2" flat washer on a 1/2"-13 x 2 1/4" bolt. If installing ShockWaves, insert the top of the shock into the shock mount on the upper crossmember with the adjusting knob to the inside. If installing CoilOver, insert the bottom of the shock into the shock mount on the upper crossmember. Line up the holes and insert the bolt/washer. Install a 1/2" flat washer and 1/2"-13 thin nylok nut on the threads and tighten to 50 ftlbs.






**31.** Install a 5/8" ID 90002067 spacer (**Small side towards shock body**) onto the lower Shock Stud. Slide the bottom of the Shock onto the Stud. Install a second 5/8" ID 90002067 Spacer onto the Stud (**small side towards shock**). You may need to jack the rear end up to Slide the Shock onto the Stud. Install the 7/16" Flat washer and 7/16" Nylok nut. Tighten the upper and lower shock bolts. Torque the Upper Bolt to 55 ftlbs and the Lower Nut to 40 ftlbs. The designed ride height of the CoilOver/ Shockwave is 14 1/2" center to center.

**Note:** If installing Shockwaves and you want to locate the air fitting in a different location, the air spring assembly can be rotated on the shock by grabbing the air spring assembly by hand and spinning it on the shock.



### Part # 24350701 - 5.2" Stroke TQ Series Shockwave

#### Recommended Tools



## 7000 Series Bellow, Eye/Eye 5.2" Shock Installation Instructions

#### Table of contents

|              |                                  |
|--------------|----------------------------------|
| Page 41..... | Included Components              |
| Page 42..... | Notes and Care of Your Shockwave |
| Page 43..... | Shock Adjustment                 |
| Page 44..... | Shock Adjustment                 |

#### ShockWave Dimensions:

|                                         |        |
|-----------------------------------------|--------|
| Center of bearing to Center of bearing: |        |
| Compressed:                             | 11.85" |
| Ride Height:                            | 14.60" |
| Extended:                               | 16.42" |


[www.ridetech.com](http://www.ridetech.com)





### Major Components .....In the box

| Item # | Part #     | Description                                       | QTY |
|--------|------------|---------------------------------------------------|-----|
| 1      | 986-10-072 | 5.2" Stroke TQ Series Shock                       | 2   |
| 2      | 815-05-022 | Shock Eyelet                                      | 2   |
| 3      | 24090799   | 7000 Series 4" Rolling Sleeve AirSpring           | 2   |
| 4      | 234-00-153 | AirSpring Locking Ring (Installed on Shock)       | 2   |
|        | 90002044   | Spacer kit - 1/2" ID and 5/8" ID (Not Shown)      | 4   |
| 6      | 026-05-000 | Reservoir Clamps                                  | 4   |
| 7      | 99050000   | Reservoir Socket Head Cap Screws                  | 12  |
| 8      | 90001994   | 5/8" ID Bearing (installed in shock and eyelet)   | 4   |
| 9      | 90001995   | Bearing Snap Ring (installed in shock and eyelet) | 8   |





### Notes and Care of your Shockwaves

#### NOTES:

**WARNING:** ATTEMPTING TO REMOVE THE AIR FITTING WILL DAMAGE IT AND VOID THE WARRANTY.

**TIGHTENING THE TOP 9/16"-18 NUT:** SNUG THE NUT DOWN AGAINST THE TOP CAP. YOU NEED TO BE ABLE TO ARTICULATE THE SHOCK BY HAND. WE TORQUE THE NUT TO 80 INLBS USING A 7/8" CROWS FOOT WRENCH ON A TORQUE WRENCH.

You can clock the airfitting location on the ShockWave by turning the AirSpring assembly of the shock. Make sure the fitting doesn't contact the frame.

When cutting the airline, use a razor blade. The cut needs to be a clean cut and square for the airline to seal properly.

*The Locking ring on the shock is NOT adjustable. These rings are set at the factory to optimize the AirSpring stroke with the shock stroke.*

---

### The care and feeding of your new ShockWaves

1. Although the ShockWave has an internal bumpstop, **DO NOT DRIVE THE VEHICLE DEFLATED RESTING ON THIS BUMPSTOP. DAMAGE WILL RESULT.** The internal bumpstop will be damaged, the shock bushings will be damaged, and the vehicle shock mounting points may be damaged to the point of failure. This is a non warrantable situation.
2. Do not drive the vehicle overinflated or "topped out". Over a period of time the shock valving will be damaged, possibly to the point of failure. This is a non warrantable situation! If you need to raise your vehicle higher than the ShockWave allows, you will need a longer unit.
3. The ShockWave is designed to give a great ride quality and to raise and lower the vehicle. **IT IS NOT MADE TO HOP OR JUMP!** If you want to hop or jump, hydraulics are a better choice. This abuse will result in bent piston rods, broken shock mounts, and destroyed bushings. This is a non warrantable situation.
4. Do not let the ShockWave bellows rub on anything. Failure will result. This is a non warrantable situation.
5. The ShockWave product has been field tested on numerous vehicles as well as subjected to many different stress tests to ensure that there are no leakage or durability problems. Failures have been nearly nonexistent unless abused as described above. If the Shockwave units are installed properly and are not abused, they will last many, many years. ShockWave units that are returned with broken mounts, bent piston rods, destroyed bumpstops or bushings, or abrasions on the bellows will not be warrantied.



### Shock Adjustment 101- Single Adjustable

#### Rebound Adjustment:

How to adjust your new shocks.

The rebound adjustment knob is located on the top of the shock absorber protruding from the eyelet.

You must first begin at the ZERO setting, then set the shock to a medium setting of 12.



-Begin with the shocks adjusted to the ZERO rebound position (full stiff). Do this by rotating the rebound adjuster knob clockwise until it stops.



-Now turn the rebound adjuster knob counter clock wise 12 clicks. This sets the shock at 12. (settings 21-24 are typically too soft for street use).

Take the vehicle for a test drive.



-if you are satisfied with the ride quality, do not do anything, you are set!

-if the ride quality is too soft increase the damping effect by rotating the rebound knob clock wise 3 clicks.

Take the vehicle for another test drive.



-if the vehicle is too soft increase the damping effect by rotating the rebound knob clock wise 3 additional clicks.



-If the vehicle is too stiff rotate the rebound adjustment knob counter clock wise 2 clicks and you are set!

Take the vehicle for another test drive and repeat the above steps until the ride quality is satisfactory.

#### Note:

One end of the vehicle will likely reach the desired setting before the other end. If this happens stop adjusting the satisfied end and keep adjusting the unsatisfied end until the overall ride quality is satisfactory.

### Shock Adjustment 101-Triple Adjustable

#### Triple Adjustable:

##### Step One: High Speed Compression



-High speed compression adjustments are used in both street driving and track tuning.

-Begin with the shocks adjusted to the ZERO high speed compression position (full stiff). Do this by rotating the high speed compression adjuster (large knob) clockwise until it stops.



-Now turn the high speed compression adjuster knob counter clock wise 20 clicks. This sets the shock at 20. (settings 21-24 are typically too soft for street use. For typical street driving the high speed compression adjuster will remain at setting 20.



### Shock Adjustment 101-Triple Adjustable continued

#### Step Two: Low Speed Compression

Low speed compression adjustment is what is typically felt during street driving.



-Begin with the shocks adjusted to the ZERO low speed compression position (full stiff). Do this by rotating the low speed compression adjuster (small knob) clockwise until it stops.

-Now turn the low speed compression adjuster knob counter clock wise 20 clicks. This sets the shock at 20. (settings 21-24 are typically too soft for street use). Take the vehicle for a test drive.

-if you are satisfied with the ride quality, do not do anything, you are set!

-if the ride quality is too soft increase the damping effect by rotating the low speed compression knob clock wise 3 clicks.

#### Take the vehicle for another test drive.



-if the vehicle is too soft increase the damping effect by rotating the low speed compression knob clock wise 3 additional clicks.

-If the vehicle is too stiff rotate the low speed compression adjustment knob counter clock wise 2 clicks and you are set!

Take the vehicle for another test drive and repeat the above steps until the ride quality is satisfactory.

#### Step 3:

Adjust rebound according to Single Adjustable instructions.

#### Note:

**One end of the vehicle will likely reach the desired setting before the other end. If this happens stop adjusting the satisfied end and keep adjusting the unsatisfied end until the overall ride quality is satisfactory.**