

GT3 Installation Hub Application Guide

All GT3 hubs have a 3-bolt mounting pattern and are interchangeable with our GT3 Wheels and all other wheel brands using a 3-bolt pattern.

Application Guide		Polished Finish	Black Finish
AMERICAN MOTORS			
1970-88	All Models (except Alliance, Encore)	10-5006	20-5006
1967-68	Ambassador, American, Rebel	10-5002	20-5002
BUICK			
1969-94	All Models	10-5006	20-5006
1967-68	All Models	10-5002	20-5002
CADILLAC			
1969-89	All Models (except telescopic)	10-5006	20-5006
CHEVROLET (EXCEPT CORVETTE)			
1969-94	All Models (except Corvette, Sprint, Spectrum '86-'88 Nova)	10-5006	20-5006
1967	Camaro	10-5002	20-5002
1967-68	Chevelle, El Camino	10-5002	20-5002
1967-69	Corvair	10-5002	20-5002
1967-68	Chevy II, Nova	10-5002	20-5002
1962-63	Chevy II, Nova	10-5002	20-5002
1967-68	Chevrolet Full-Size	10-5002	20-5002
1957-63	Chevrolet Full-Size	10-5002	20-5002
CORVETTE			
1967	All Models	10-5002	20-5002
CHEVROLET/GMC TRUCKS			
1974-94	All Pick-Ups, Suburban, Blazer, Jimmy, S-10	10-5006	20-5006
1960-69	All Pick-Ups, Suburban, Blazer, Jimmy	10-5002	20-5002
1968-88	El Camino, Sprint, Caballero	10-5006	20-5006
1967-68	El Camino, Sprint	10-5002	20-5002
1982-94	Chevy/GMC Vans (inc. Astro, Safari, Lumina Van)	10-5006	20-5006
1968-69	Chevy/GMC Van	10-5002	20-5002
DODGE/CHRYSLER/PLYMOUTH AUTOS			
1978-81	All Models (Tilt Columns Only)	10-5006	20-5006
1970-87	All Models with Standard Column (except Omni, Horizon, Rampage, Daytona, Shelby Charger, Shadow, Sundance)	10-7014	20-7014
DODGE/CHRYSLER/PLYMOUTH TRUCKS & VANS			
1979-81	2WD & 4WD Pick-up, Trail-Duster, Ramcharger, Van (Tilt Columns Only)	10-5006	20-5006
1970-87	Dodge Plymouth 2 WD Std. Column, Full-size Pickups, Dakota	10-7014	20-7014
1978-87	Vans with Standard Column Including Caravan and Voyager	10-7014	20-7014
FORD LINCOLN MERCURY AUTOS			
1978-80	All Models (with horn on steering wheel): Fiesta (No coverage)	10-6009	20-6009
1970-77	All Models (Capri, Pantera, No coverage)	10-6009	20-6009
1965-70	Falcon, Comet	10-6004	20-6004
1965-69	Mercury (ALL Models)	10-6004	20-6004
1967-69	Galaxie, LTD	10-6004	20-6004
1964-69	Thunderbird	10-6004	20-6004
1968-78	Mustang, Fairlane	10-6009	20-6009
1964-67	Mustang (with alternator)	10-6004	20-6004
1963½-64	Mustang (w/gen.), Falcon, Comet	10-6005	20-6005
FORD TRUCKS & VANS			
1978-91	Pick-up – Full-size	10-6009	20-6009
1970-77	Pick-up – Full-size	10-6005	20-6005
1970-79	Ranchero	10-6009	20-6009
1969	Pick-up	10-6009	20-6009
1968	Pick-up	10-6005	20-6005
1967	Pick-up	10-6004	20-6004
1965-69	Ranchero	10-6004	20-6004
1965-66	Pick-up – except Econoline	10-6005	20-6005
1978-91	Bronco – Full-size	10-6009	20-6009
1975-77	Bronco	10-6005	20-6005
1967-74	Bronco	10-6004	20-6004
1978-91	Van – Full-size	10-6009	20-6009
1975-77	Van – Full-size	10-6005	20-6005
JEEP			
1976-95	CJ5, CJ6, CJ7, Wrangler, Cherokee, Wagoneer, Pick-up, Scrambler, Comanche	10-5006	20-5006
1976-86	Models with Optional OEM Wheel	10-5002	20-5002
1974-75	Cherokee, Wagoneer, Pick-up	10-5006	20-5006
OLDSMOBILE			
1969-94	All Models	10-5006	20-5006
1967	All Models	10-5002	20-5002
1949-63	All Models (except Cutlass)	10-5002	20-5002
PONTIAC			
1969-94	All Models (except 1988-on LeMans)	10-5006	20-5006
1967-68	All Models	10-5002	20-5002
1949-63	All Other Models (except GTO, Tempest, LeMans)	10-5002	20-5002
PORSCHE			
1960-61	All Models	10-8005	20-8005
VOLKSWAGEN			
1960-73	All Models – Autos	10-8005	20-8005
SPECIALTY APPLICATIONS			
CUSTOM STEERING COLUMNS			
All	Flaming River Columns (GM Columns Only)	10-5006	20-5006
All	Ididit Columns (GM Columns Only)	10-5006	20-5006

NOTICE:

Airbag Equipped Vehicles: GT Performance Products Steering Wheels and Hubs are not designed for use on Airbag Equipped Vehicles. Due to Safety and Legal reasons, we do not recommend changing, altering or removing the airbag from any vehicle.

Cruise Control: GT Performance Installation Hubs will not fit on vehicles with factory cruise control in the wheel.

Telescopic Columns: GT Performance Installation Hubs will not fit on vehicles with telescopic columns.