

GT9 Installation Hub Application Guide

All GT9 hubs have a 9-bolt mounting pattern and are interchangeable with our GT9 Wheels and all other wheel brands using a 9-bolt pattern.

Application Guide		Polished Finish	Black Finish
AMERICAN MOTORS			
1970-88	All Models (except Alliance, Encore)	10-5506	20-5506
1967-68	Ambassador, American, Rebel	10-5502	20-5502
BUICK			
1969-94	All Models	10-5506	20-5506
1967-68	All Models	10-5502	20-5502
CADILLAC			
1969-89	All Models (except telescopic)	10-5506	20-5506
CHEVROLET (EXCEPT CORVETTE)			
1969-94	All Models (except Corvette, Sprint, Spectrum '86-'88 Nova)	10-5506	20-5506
1967	Camaro	10-5502	20-5502
1967-68	Chevelle, El Camino	10-5502	20-5502
1967-69	Corvair	10-5502	20-5502
1967-68	Chevy II, Nova	10-5502	20-5502
1962-63	Chevy II, Nova	10-5502	20-5502
1967-68	Chevrolet Full-Size	10-5502	20-5502
1957-63	Chevrolet Full-Size	10-5502	20-5502
CORVETTE			
1967	All Models	10-5502	20-5502
CHEVROLET/GMC TRUCKS			
1974-94	All Pick-Ups, Suburban, Blazer, Jimmy, S-10	10-5506	20-5506
1960-69	All Pick-Ups, Suburban, Blazer, Jimmy	10-5502	20-5502
1968-88	El Camino, Sprint, Caballero	10-5506	20-5506
1967-68	El Camino, Sprint	10-5502	20-5502
1982-94	Chevy/GMC Vans (inc. Astro, Safari, Lumina Van)	10-5506	20-5506
1968-69	Chevy/GMC Van	10-5502	20-5502
DODGE/CHRYSLER/PLYMOUTH AUTOS			
1978-81	All Models (Tilt Columns Only)	10-5506	20-5506
1970-87	All Models with Standard Column (except Omni, Horizon, Rampage, Daytona, Shelby Charger, Shadow, Sundance)	10-7514	20-7514
DODGE/CHRYSLER/PLYMOUTH TRUCKS & VANS			
1979-81	2WD & 4WD Pick-up, Trail-Duster, Ramcharger, Van (Tilt Columns Only)	10-5506	20-5506
1970-87	Dodge Plymouth 2 WD Std. Column, Full-size Pickups, Dakota	10-7514	20-7514
1978-87	Vans with Standard Column Including Caravan and Voyager	10-7514	20-7514
FORD LINCOLN MERCURY AUTOS			
1978-80	All Models (with horn on steering wheel): Fiesta (No coverage)	10-6509	20-6509
1970-77	All Models (Capri, Pantera, No coverage)	10-6509	20-6509
1965-70	Falcon, Comet	10-6504	20-6504
1965-69	Mercury (ALL Models)	10-6504	20-6504
1967-69	Galaxie, LTD	10-6504	20-6504
1964-69	Thunderbird	10-6504	20-6504
1968-78	Mustang, Fairlane	10-6509	20-6509
1964-67	Mustang (with alternator)	10-6504	20-6504
1963½-64	Mustang (w/gen.), Falcon, Comet	10-6505	20-6505
FORD TRUCKS & VANS			
1978-91	Pick-up – Full-size	10-6509	20-6509
1970-77	Pick-up – Full-size	10-6505	20-6505
1970-79	Ranchero	10-6505	20-6509
1969	Pick-up	10-6509	20-6509
1968	Pick-up	10-6505	20-6505
1967	Pick-up	10-6504	20-6504
1965-69	Ranchero	10-6504	20-6504
1965-66	Pick-up – except Econoline	10-6505	20-6505
1978-91	Bronco – Full-size	10-6509	20-6509
1975-77	Bronco	10-6505	20-6505
1967-74	Bronco	10-6504	20-6504
1978-91	Van – Full-size	10-6509	20-6509
1975-77	Van – Full-size	10-6505	20-6505
JEEP			
1976-95	CJ5, CJ6, CJ7, Wrangler, Cherokee, Wagoneer, Pick-up, Scrambler, Commanche	10-5506	20-5506
1976-86	Models with Optional OEM Wheel	10-5502	20-5502
1974-75	Cherokee, Wagoneer, Pick-up	10-5506	20-5506
OLDSMOBILE			
1969-94	All Models	10-5506	20-5506
1967	All Models	10-5502	20-5502
1949-63	All Models (except Cutlass)	10-5502	20-5502
PONTIAC			
1969-94	All Models (except 1988-on LeMans)	10-5506	20-5506
1967-68	All Models	10-5502	20-5502
1949-63	All Other Models (except GTO, Tempest, LeMans)	10-5502	20-5502
PORSCHE			
1960-61	All Models	10-8505	20-8505
VOLKSWAGEN			
1960-73	All Models – Autos	10-8505	20-8505
SPECIALTY APPLICATIONS			
CUSTOM STEERING COLUMNS			
All	Flaming River Columns (GM Columns Only)	10-5506	20-5506
All	Ididit Columns (GM Columns Only)	10-5506	20-5506

NOTICE:

Airbag Equipped Vehicles: GT Performance Products Steering Wheels and Hubs are not designed for use on Airbag Equipped Vehicles. Due to Safety and Legal reasons, we do not recommend changing, altering or removing the airbag from any vehicle.

Cruise Control: GT Performance Installation Hubs will not fit on vehicles with factory cruise control in the wheel.

Telescopic Columns: GT Performance Installation Hubs will not fit on vehicles with telescopic columns.