

INSTRUCTIONS

© 2024, Speedway Motors, Inc.

SPEEDWAY
motors®

910-98210 - E-Brake Pedal Pads

Kit Contents		
Qty	Part #	Description
1	910-98210.1	E-Brake Pedal Pad (Polished, Black or Brushed)
1	910-98210.2	Hardware Kit

1. Begin by removing the old rubber pedal pad from the pedal assembly. Clean the steel pedal to remove any old rubber or adhesive before attempting to install the new pedal pad.
2. Test fit the new pedal pad to ensure proper fit. In some instances, due to variations in the OEM pedals, it may be necessary to file the edge of the pedal to allow the pedal pad to fully seat.
3. Once you are happy with the fit up, mark and center punch for the mounting holes.
4. Remove the pedal pad and drill the 3/16" holes for the mounting screws.
5. Deburr the holes as required, and test fit the pedal pad with the mounting screws to ensure alignment.
6. If all looks good, install the new pedal pad to the pedal and retain using the #8-32 x 3/4" long flat head screws and lock nuts as shown.

The 910-98210 E-Brake pedal pad uses two screws and nuts..

