



509 Hemlock St
Phillipsburg, PA 16866
Ph- 814.343.6315 Fax- 814.343.6318
Installation Instructions
support@umiperformance.com
www.umiperformance.com

1979-2004 Ford Mustang Tubular Lower Control Arms Item # 1021 & 1022

1. Block front wheels and jack vehicle up to good working height. Position jack stands under vehicle frame to allow rear end to hang freely. Make sure car is stable.
2. Remove both the rear wheels and OEM sway bar. Disconnect both the passenger side and drivers side quad shocks.
3. Disconnect the exhaust from the H-pipe and let it rest on the axle. This allows access to the front control arm bolts. There is no need to remove the muffler/tailpipe assembly from the vehicle.
4. Jack up the rear end and disconnect the rear shocks at there lower mounting points. Now lower the rear all the way down and remove the coil springs. Leave the jack under the rear end to keep it from falling. You may even wish to reinstall the shock bolts to also hold the rear end up.
5. With the coil springs removed the lower control arms may now be removed. Only remove one side at a time. Removing both control arms at once will allow the rear end to shift forward making the installation more difficult.
6. Using 18mm wrenches/socket remove both front and rear control arm bolts, remove control arm from vehicle.
7. Install the UMI lower control arm into place. Do not tighten bolts yet, the vehicle's weight must on the rear axle before tightening to prevent bushing preload.
8. Repeat steps 6 - 8 on opposite side.
9. With both new control arms in place raise the rear end and remove the lower shock bolts. Let the rear end down until there is enough room to reinstall the coil springs, you may wish to use a spring compressor but it should not be necessary. With the coil springs installed raise the rear end back up and reinstall the lower shock bolts and tighten.
10. Reattach the exhaust and install sway bar using OEM hardware from step 2. Install wheels.
11. Jack up vehicle by rear axle, remove jack stands from frame and place under rear axle. Release the jack and let the vehicle weight rest on the jack stands.
12. Tighten all (4) control arm mounting bolts and lube each grease fitting with 1-1 ½ pumps of grease **only**. Recommended torque spec on lower control arms is 72 ft lbs.

Greasing Your Control Arms- Use marine type grease, marine type grease can not be washed away with water. Grease your control arm bushings 2-3 times a year adding only 1 pump of grease, **DO NOT OVER GREASE**.

Thank you for Putting Your Trust in A UMI Performance Product!
www.umiperformance.com

DISCLAIMER OF WARRANTY

THE PURCHASER ACCEPTS ALL RESPONSIBILITY FOR THE FINAL USE OF THE PRODUCTS PURCHASED AND SHALL HOLD UMI PERFORMANCE INCORPORATED AND ITS REPRESENTATIVES HARMLESS IN ANY LEGAL PROCEEDING ARISING FROM THE USE OF SUCH PRODUCTS.

UMI PERFORMANCE INCORPORATED DOES NOT WARRANT, GUARANTEE, OR MAKE ANY REPRESENTATION REGARDING THE USE, OR THE RESULT OF THE USE OF ANY PERFORMANCE PRODUCT MANUFACTURED OR DISTRIBUTED BY UMI PERFORMANCE INCORPORATED. PURCHASER ASSUMES THE ENTIRE RISK AS THE RESULT AND PERFORMANCE OBTAINED FROM THE INSTALLATION AND USE OF SAID PERFORMANCE PRODUCTS. UMI PERFORMANCE INCORPORATED ASSUMES NO RESPONSIBILITY FOR AND HEREBY DISCLAIMS ALL WARRANTIES, ORAL OR WRITTEN, EXPRESS OR IMPLIED INCLUDING WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE.

ALL PARTS ARE WARRANTED TO BE FREE OF DEFECT AT THE TIME OF PURCHASE. WARRANTY IS ONLY EXTENDED TO REPLACEMENT OF PARTS FROM UMI PERFORMANCE INCORPORATED AND DOES NOT COVER LABOR, TOWING OR ANY OTHER DIRECT OR INDIRECT COST. UMI PERFORMANCE INCORPORATED IS NOT RESPONSIBLE FOR ANY CONSEQUENTIAL DAMAGE, EXPENSE OR INJURY ARISING FROM THE USE, MISUSE OR IMPROPER INSTALLATION OF ANY PRODUCT MANUFACTURED AND/OR SOLD BY UMI PERFORMANCE INCORPORATED.

Item # 1022

2005-Present Mustang Upper Control Arm
UMI Performance Inc.
Made in Pennsylvania, USA