


720-4037



PART NO. 4037
1952-64 FORD PICKUP MOUNT

INSTALLATION INFORMATION

1. With the engine suspended by a chain hoist or other suitable device, place the Trans-Dapt crossmember mount between the frame rails with mounting tabs laying on top of the frame rail channels.
2. Bolt the OEM Ford motor mount pads (part No. C6VY-6038-C) to the engine block and lower onto the crossmember. Bolt the pads to the crossmember mounting brackets.
3. Drill two holes through each crossmember mounting tab, and on through the frame rails. Install bolts supplied with kit.

This mount allows installation of the 332, 352, 390, 406, 427 and 428 cubic inch Ford V8 engines into 1952-64 Ford pickup chassis.

16410 MANNING WAY • CERRITOS, CA. 90701 • (213) 404-2985