





**Part # 12162401** - 60-64 Ford Galaxie Front HQ Shockwave, OEM Control Arms

### Recommended Tools



## 1000 Series Bellow, 2.0" Stud/Trunnion 2.9" Shock Installation Instructions

**THE CONTROL ARMS NEED TO BE REINFORCED IN THE AREA THAT THE TRUNNION BOLTS TO.**

### Table of contents

Page 2..... Included components

Page 3-4..... Shockwave Installation

Page 5-6..... Notes and Care of Your Shockwave & Shock Adjustment

### ShockWave Dimensions:

Mount to Mount:

Compressed: 9.60"

Ride Height: 11.00"

Extended: 11.90"

THE DELRIN BALL REQUIRES A 3/4" HOLE FOR THE FLANGE TO GO THROUGH. THIS CAN BE DRILLED WITH A UNIBIT.

[www.ridetech.com](http://www.ridetech.com)  
812-482-2932






### Major Components .....In the box

**THE CONTROL ARMS NEED TO BE REINFORCED IN THE AREA THAT THE TRUNNION BOLTS TO.**

| Item # | Part #   | Description                                                       | QTY |
|--------|----------|-------------------------------------------------------------------|-----|
| 1      | 24129999 | 2.9" Stroke HQ Series Shock                                       | 2   |
| 2      | 90009986 | 2" Stud Top (Installed on Shock) - Includes Adjuster Knob & Screw | 2   |
| 3      | 24090199 | 1000 Series 6.5" Double Convolute AirSpring                       | 2   |
| 4      | 70010893 | AirSpring Locking Ring (Installed on shock)                       | 2   |
| 5      | 99055000 | Locking Ring Set Screw (Installed on shock)                       | 2   |
| 6      | 90002060 | Universal Trunnion                                                | 4   |
| 7      | 90002312 | 2" Aluminum Stud Top Base                                         | 2   |
| 8      | 90001904 | Bottom Delrin Ball                                                | 2   |
| 9      | 90001903 | Top Delrin Ball                                                   | 2   |
| 10     | 90001902 | Delrin Ball Aluminum Top Cap                                      | 2   |
| 11     | 99562003 | 9/16"-18 Thin Nylok Nut                                           | 2   |
| 12     | 90009972 | Adjuster Knob - (90009986 assembly)                               | 2   |
| 13     | 90009969 | #4-40 X 1/4" SS, 18-8 Pan Head Torx Cap - (90009986 assembly)     | 2   |
| 14     | 90001980 | Trunnion Locking Rings                                            | 4   |
|        | 70012160 | 2" Stud Top Metering Rod (installed in stud top)                  | 2   |
|        | 90001994 | 5/8" ID Bearing (installed in shock and eyelet)                   | 4   |
|        | 90001995 | Bearing Snap Ring (installed in shock and eyelet)                 | 8   |
|        | 99311002 | 5/16" X 1 1/4" Hex Bolt                                           | 4   |
|        | 99312003 | 5/16"-18 Nylok Nut                                                | 4   |
|        | 99313002 | 5/16" SAE Flat Washer                                             | 8   |



**THE DELRIN BALL REQUIRES A 3/4" HOLE FOR THE FLANGE TO GO THROUGH. THIS CAN BE DRILLED WITH A UNIBIT.**




### ShockWave Installation



1. Raise and support vehicle at a safe, comfortable working height. Let the front suspension hang freely.


2. Remove the coil spring and shock absorber. Refer to factory service manual for proper disassembly procedure.

3. The upper shock hole needs drilled to 3/4". A Unibit works well for drilling the hole.



4. Trim the coil spring location ring flush to prevent the ring from hitting the top of the ShockWave Air Spring. A die grinder with a cutoff wheels works well here.

**Allowing the Shockwave to touch the frame at any point through full suspension travel will damage the unit and is not warrantable.**




5. The Shockwave trunnion sits on top of the arm as opposed to the factory shock, which bolts to the bottom side of the car. You will have to remove the two OEM nuts that retain the original shock.



### ShockWave Installation

6.



**Note:** The airline must also be routed at this time. It can be ran through the subframe toward the rear of the vehicle.

6. Apply thread sealant to a 90 degree air fitting and screw it into the top of the Shockwave. The air fitting location can be rotated by twisting the bellow assembly separate of the shock. Place the Shockwave into the coil spring pocket with the stud sticking through the OEM shock hole. See assembly **Diagram 6**. OEM Shock hole **must** be drilled out to  $\frac{3}{4}$ "

1. Stud top aluminum base
2. Delrin ball lower half
3. Delrin ball upper half
4. Aluminum cap
5. 9/16" SAE Nylok jam nut
6. Threaded stud (screwed onto shock shaft)
7. Rebound adjusting knob
8. Screw


**THE CONTROL ARMS NEED TO BE REINFORCED IN THE AREA THAT THE TRUNNION BOLTS TO.**

7. Raise the lower arm up to the Shockwave and bolt them together using the 5/16" x 1 1/4" Bolts, Washers, & Nylok Nuts supplied with the ShockWaves. Torque to 17 ftlbs.

8. Raise the lower control arm to full compression and double-check to make sure the Shockwave does not rub on anything at any-time. Allowing the Shockwave to rub on anything will cause failure and is not a warrantable situation.

9. Ride height should be around 90 psi but will vary to vehicle weight and driver preference.

7.





## Installation Instructions



### Notes and Care of your Shockwaves

#### NOTES:

**TIGHTENING THE TOP 9/16"-18 NUT:** SNUG THE NUT DOWN AGAINST THE TOP CAP. YOU NEED TO BE ABLE TO ARTICULATE THE SHOCK BY HAND.

You can clock the airfitting location on the ShockWave by turning the AirSpring assembly of the shock.

When cutting the airline, use a razor blade. The cut needs to be a clean cut and square for the airline to seal properly.

The Locking ring on the shock is **NOT** adjustable. These rings are set at the factory to optimize the AirSpring stroke with the shock stroke.

---

## The care and feeding of your new ShockWaves

1. Although the ShockWave has an internal bumpstop, **DO NOT DRIVE THE VEHICLE DEFLATED RESTING ON THIS BUMPSTOP. DAMAGE WILL RESULT.** The internal bumpstop will be damaged, the shock bushings will be damaged, and the vehicle shock mounting points may be damaged to the point of failure. This is a non warrantable situation.
2. Do not drive the vehicle overinflated or "topped out". Over a period of time the shock valving will be damaged, possibly to the point of failure. This is a non warrantable situation! If you need to raise your vehicle higher that the ShockWave allows, you will need a longer unit.
3. The ShockWave is designed to give a great ride quality and to raise and lower the vehicle. **IT IS NOT MADE TO HOP OR JUMP!** If you want to hop or jump, hydraulics are a better choice. This abuse will result in bent piston rods, broken shock mounts, and destroyed bushings. This is a non warrantable situation.
4. Do not let the ShockWave bellows rub on anything. Failure will result. This is a non warrantable situation.
5. The ShockWave product has been field tested on numerous vehicles as well as subjected to many different stress tests to ensure that there are no leakage or durability problems. Failures have been nearly nonexistent unless abused as described above. If the Shockwave units are installed properly and are not abused, they will last many, many years. ShockWave units that are returned with broken mounts, bent piston rods, destroyed bumpstops or bushings, or abrasions on the bellows will not be warrantied.



### Shock Adjustment

#### Shock adjustment 101- Single Adjustable

##### Rebound Adjustment:

How to adjust your new shocks.

The rebound adjustment knob is located on the top of the shock absorber protruding from the eyelet.

You must first begin at the ZERO setting, then set the shock to a soft setting of 20.



-Begin with the shocks adjusted to the ZERO rebound position (full stiff). Do this by rotating the rebound adjuster knob clockwise until it stops.



-Now turn the rebound adjuster knob counter clock wise 20 clicks. This sets the shock at 20. (settings 21-24 are typically too soft for street use).

##### Take the vehicle for a test drive.



-if you are satisfied with the ride quality, do not do anything, you are set!

-if the ride quality is too soft increase the damping effect by rotating the rebound knob clock wise 3 clicks. **CONTINUE ON NEXT PAGE.**

##### Take the vehicle for another test drive.



-if the vehicle is too soft increase the damping effect by rotating the rebound knob clock wise 3 additional clicks.



-If the vehicle is too stiff rotate the rebound adjustment knob counter clock wise 2 clicks and you are set!

Take the vehicle for another test drive and repeat the above steps until the ride quality is satisfactory.

##### Note:

One end of the vehicle will likely reach the desired setting before the other end. If this happens stop adjusting the satisfied end and keep adjusting the unsatisfied end until the overall ride quality is satisfactory.

### STILL HAVE QUESTIONS?

#### Tech line hours

Monday - Friday

8AM - 6PM (EST) ..... 812-482-2932