



350 S. St. Charles St. Jasper, In. 47546  
Ph. 812.482.2932 Fax 812.634.6632

[www.ridetech.com](http://www.ridetech.com)

**Part # 13013699**  
**Chrysler B & E Body Front Upper StrongArms**

**Upper StrongArms**

|   |          |                                       |
|---|----------|---------------------------------------|
| 1 | 90000602 | Driver side upper arm                 |
| 1 | 90000603 | Passenger side upper arm              |
| 4 | 90000918 | Bushings ( <b>Pressed into arms</b> ) |
| 2 | 90000895 | Ball joint                            |

# ridetech

350 S. St. Charles St. Jasper, In. 47546  
Ph. 812.482.2932 Fax 812.634.6632

[www.ridetech.com](http://www.ridetech.com)



1. Remove factory upper arm.
2. Bolt StrongArm to frame using factory bolts. (Do not tighten yet.)
3. Slide ball joint boot over ball joint stud. Push stud through spindle. Secure w/ the castle nut and cotter pin supplied. The supplied spacer may be need to achieve proper castle nut to cotter pin hole alignment.
4. Install grease fitting and lubricate ball joint.
5. Position the suspension at ride height (about mid travel) and tighten upper arm bolt.
6. Vehicle may need to be realigned before driving.

