Installation Instructions for Speedway Motors Part Number: 911-7002

1. Support the hood with an assistant or hood prop.
2. Remove the original hood spring mechanism.





3. Install the angle bracket on both sides of the hood. There is an existing hole in the hood for this. Fasten using the supplied ¼" button head cap screw and flanged nut.



4. Note there are (2) different styles of ball stud. Install the ball stud with the short hex on the brace, as shown, and tighten the metric flanged nut.



5. Install the brace in the hood as shown using ¼"

hex head cap screws and flanged nuts. Note the ball stud is closer to the cowl than the front of the car.



6. Install the ball stud with the long hex in the existing hole in the fender, as shown, and tighten the metric flanged nut.



7. Install the gas strut with the rod down. The ends of the gas strut will easily snap over the ball studs.



8. Be very cautious when closing the hood for the first time. The gas struts apply a different force to the hood than the original springs. A loosening of the hood hinges and re-adjustment of the hood may be necessary.

911-7002 Includes These Parts



PO Box 81906
Lincoln NE 68501-1906
1-800-979-0122