


Pro-Billet Distributor Installation

WARNING: High voltage is present on the coil terminals. Do not touch the terminals or coil tower when the engine is cranking or running.



Wiring to an Ignition Control.