

INSTRUCTIONS

© 2021, Speedway Motors, Inc.

SPEEDWAY
motors

910-31367 - Adjustable Proportioning Block

Mounting:

1. Select a suitable mounting location for the block assembly. In general, the necessary line connections will be simpler with the block located near the master cylinder. If vehicle has a factory combination block bracket, the prop block can be mounted to that, otherwise the block can be mounted to an inner fender or frame rail.
2. Secure the block using 5/16" hardware of the appropriate length for your specific application.

Line Connections:

1. All of the in and out connections on the block are 3/8"-24 thread with an SAE flare for a standard 3/16" brake line. The supplied tube nuts can be flared onto any 3/16" brake line. However, it is not necessary to use these as long as the lines you are using have a 3/8"-24 fitting already flared on.
2. Connect the front brake outlet of the master cylinder to the port marked "F I" on the top of the prop block. The outlet of the master cylinder for the front brakes will typically be the one for the larger reservoir. If reservoirs are the same size, a good rule of thumb is that the front reservoir feeds the front brakes on GM mastercylinders, while the rear reservoir feeds the front brakes on Ford and Mopar master cylinders.
3. Next, connect the two ports marked "F O" on the front and bottom of the prop block to the lines feeding the front brakes of the vehicle. Most vehicles will have two separate brake lines: one feeding the left (driver) front wheel and one feeding the right (passenger) front. If your vehicle uses only one front brake line to feed both wheels, it is acceptable to plug the remaining front outlet port of the prop block.
4. Connect the rear brake outlet port of the master cylinder to the port marked "R I" on the top of the prop block.

5. Connect the port marked "R O" on the back of the prop block to the line feeding the rear brakes. If your vehicle is equipped with a 1/4" rear brake line, use the supplied adapter fitting to connect the line to the outlet of the prop block. Speedway Motors has supplied the 1/4" adapter for the most popular sizes. In the event that this fitting will not fit your line, you will need to locate a fitting from your local parts store.
6. Tighten all fittings using a tube wrench and be sure to check for any leaks after the brake system is bled.

Switch Connections:

1. The switch supplied with the prop block is a pressure switch designed to activate the brake lights on vehicle (and not the brake warning light on your dash). If your vehicle is equipped with a brake light switch on the brake pedal, the switch in the prop block will not be used. If your vehicle has no other brake light switch, then this switch must be properly connected for the brake lights to function.
2. Your brake lights should already be connected to a chassis ground, The switch supplied will be used to send power to the brake lights when pressure is applied to the brake system.
3. Connect the orange wire of the supplied pig tail to a fused constant 12V power supply. A 15-amp circuit should be appropriate for most vehicles.
4. If your vehicle has separate circuits for the brake lights and turn signals, then the white wire of the pigtail can be extended to the back of the vehicle and used to power the brake light pigtails in the taillights. If your vehicle uses the same circuit for brake lights and turn signals, the the white wire will be run to your turn signal switch, Refer to the wiring diagram for your specific turn signal switch for the proper connections.


910-31367 - Adjustable Proportioning Block

Brake Bleeding:

1. After the installation of the prop block is complete, it will be necessary to bleed the brake system.
2. If the master cylinder is new or went dry at any time during the installation, begin by bench bleeding the master cylinder.
3. Continue the bleeding process by gravity bleeding the caliper or wheel cylinder at each wheel until no air bubbles are seen in the escaping brake fluid. Start with the wheel farthest from the master cylinder and work your way closer bleeding each wheel. Never let the master cylinder go dry at any time during this process.
4. With all the bleeding complete, a firm consistent pedal feel should be achieved. If the vehicle already had a functioning brake system prior to the installation of the prop block, there should be no significant change in the pedal feel.
5. With all bleeding complete, check all the fittings for leaks and tighten as necessary.

Proportioning Valve Adjustment

1. The proportioning valve in the prop block will be used to adjust the rear brake pressure of the vehicle. The objective is to balance the pressure of the rear brakes to the front so that under hard braking, the rear brakes do not lock up before the fronts.
2. Start with the valve in the full increase position by turning the knob all the way in, in a clockwise rotation.
3. Find a safe open area such as a parking lot and make several hard stops from 30 mph observing the function of the rear brakes. If the rear brakes lock up well before the front, begin to decrease the rear brake pressure by turning the knob in a counter clockwise rotation. Continue these adjustments until the proper balance is found.
4. When you have found the proper adjustment for your vehicle, try the test again at 50 mph and make further adjustments as necessary.



IMPORTANT

DISCLAIMER In an effort to offer our customers low prices, quick service and great value, Speedway Motors reserves the right to change suppliers, specifications, colors, prices, materials without notice. Prices and policies that were current and in effect at the time of printing are also subject to change without notice. Quantities are limited on some items. Any unauthorized use of this catalog including words, photos or drawings is prohibited. Speedway is not responsible for any typographical errors, printing errors or misinterpretations

WARRANTY DISCLAIMER Purchasers understand and recognize that racing parts, specialized street rod equipment, and all other parts and services sold by Speedway Motors, Inc. are exposed to many and varied conditions due to the manner in which they are installed and used. Except for certain limited warranties, if any, set forth in Speedway Motors, Inc.'s current catalog with respect to the products and/or parts thereof identified on your invoice, each product, and each part thereof, is sold "as is", and "with all faults" and Speedway Motors, Inc. makes no warranties either expressed or implied, written or oral, with regard such products and services including, without limitation, any warranty of merchantability or fitness for a particular purpose. Without limiting the foregoing, there is no warranty expressed or implied as to whether the goods sold hereby will protect purchasers or ultimate end-users of such products and parts from injury or death. In no event shall Speedway Motors, Inc. be liable for any special, incidental or consequential damages, or any other damages whatsoever arising out of or connected with the use or misuse of the products and each part thereof. Purchasers acknowledge and agree that no person, entity or agent of Speedway Motors, Inc. has any authority to make any statement contrary to this disclaimer and that any warranty statements or representations allegedly made on behalf of Speedway Motors, Inc. by any such person, entity or agent are void. Purchasers are relying solely on their own skill and judgment to select, purchase and use suitable products and assume all responsibility and risk with regard thereto. Some local laws prohibit the use of utility jugs, funnels and barrel pumps for dispensing fuel. Please check your own state for more information, regulations or further direction in your use of the utility jugs, funnels and barrel pump described in Speedway's catalogs or on Speedway Motors websites. Some parts in this catalog are not legal for sale or use in California. Items sold in this catalog are for racing vehicles which may never be used on a highway. The use of manufacturer's names and symbols are for reference purposes only.

DAMAGE CLAIMS Please inspect all packages upon delivery and in the presence of the delivery driver when possible. The driver must note any visible damage and provide procedures for handling damage claims. To allow for a claims process, please retain original box, packing material and damaged merchandise. Contact Speedway Motors for instructions regarding damage claim within 5 days of receipt. Speedway Motors assumes no liability after this period.

SHORTAGES Please check the contents of your delivery to ensure that all parts ordered are received. Refer to your invoice to cross check all items received and inspect all packing materials for contents of small items. Retain original shipping box and packing materials. Orders may be split into multiple boxes which can be delivered on different days. Contact Speedway Motors for instructions regarding shortage claim within 5 days of receipt. Speedway Motors assumes no liability after this 5 day period.

REFUSALS All refused packages will be billed the freight to and from the destination and refused COD orders will be billed a 15% restocking charge plus freight to and from destination.

WARRANTY CLAIMS If the item is used or installed and a warranty claim request is submitted, warranty work is done by the manufacturer and may take up to 30 days for processing. Speedway Motors will be required to follow the manufacturer's warranty instructions to allow for a credit refund or exchange when specified.

RETURNS We want you to be satisfied with your purchase. If you are not satisfied, you may return your new, unused item within 60 days for refund or exchange.

All exchanged or returned merchandise must be in original factory condition with no modifications or alterations. Returned merchandise must include original packaging materials, warranty cards, manuals, instructions, etc. If the returned item requires repackaging, your refund / exchange will be subject to a repackaging charge. Return/Exchange transactions less than \$99 are excluded from the free shipping offer.

HOW TO RETURN AN ITEM Please re-pack the item in a sturdy box, include a copy of your invoice and completed return form. Returns must be shipped prepaid. CODs are not accepted. Shipping costs for exchanged merchandise will be charged to your credit card.

Items that are returned after 60 days are subject to a 15% restocking charges. Fiberglass items returned will be subject to a 15% restocking charge. We are unable to accept returns on electrical parts, video tapes, DVD's, books, special order or closeout merchandise.

BRAKE INSTALLATION ALERT The selection and installation of brake components should only be done by personnel experienced in the proper installation and operation of braking systems. The installer must use his/her own discretion to determine the suitability of all brake components and brake kits for every particular application. Speedway Motors, Inc. makes no warranties either expressed or implied including any warranty of merchantability or fitness for a particular purpose, other than those contained in its current catalog or website with respect to the goods identified on the face of the invoice. There is no warranty expressed or implied as to whether the goods sold hereby will protect the purchaser or ultimate user of such goods from injury or death.

EXHAUST INSTALLATION ALERT Exhaust systems and other component surface finishes are not permanent. Coatings, paint and other factory supplied cosmetic treatments are only intended to protect from surface corrosion in an unused state. No returns are allowed after the parts have been installed. Header flanges must be clean and clear of paint and surface contaminants prior to mating to exhaust gaskets. Exhaust fasteners must be re-torqued after the initial heat cycle and regularly thereafter to ensure a proper gasket seal is maintained. Should you decide to install this exhaust product at your home, be warned that pleasure car or light duty truck/van "bumper" jacks are intended for emergency use only. The use of frame contact jack stands in conjunction with a floor jack as a main support is highly recommended to minimize accidental dropping of a vehicle while the installation proceeds. We recommend the use of a shop hoist if possible. Please use caution! Speedway Motors, Inc. makes no warranties either expressed or implied including any warranty of merchantability or fitness for a particular purpose, other than those contain in its current catalog or website with respect to the goods identified on the face of the invoice. There is no warranty expressed or implied as to whether the goods sold hereby will protect the purchaser or ultimate user of such goods from injury or death.

CHECK LOCAL LAW Some parts are not legal for sale or use in California on any pollution controlled motor vehicles. These items are legal in California for racing vehicles only which may never be used upon a highway. Check local law.

Find the above info on our website:

SpeedwayMotors.com/Info/FAQ

© 2021, Speedway Motors, Inc.

Speedway Motors, Inc.

P.O. Box 81906 • Lincoln, NE 68501

800.979.0122 • SpeedwayMotors.com

