

Axle Cradle Dolly

Made in
the USA



Photo contributed



- Weight capacity: 500 lbs
- Features Four easy-rolling Heavy Duty Casters
- Painted finish

The benefits of this dolly should be easy to see! Allows **one** person to easily roll an entire axle/differential around your shop!

Use along with our handy **Axle Hoist** & a single person can use a cherry picker to lift the axle/differential on & off of the Axle Cradle Dolly, too!

www.theAutoDolly.com 308-384-7423 ext. 188

MERRICK
The Auto Dolly & Merrick Originals

Parts Number: M998067

*Specifications subject to change without notice



Step 1: Attach the hub to the Hoist Couplers on each side. It is designed to fit virtually all bolt patterns. Use a minimum of two lug nuts. Three are highly recommended.

Step 2: Attach the top junction piece securely to your "cherry picker". Attach the chain from each side's hoist couplers to the top junction piece.



Step 3: Carefully raise the arm of the "cherry picker" to safely lift the axle off the floor. For maximum stability, keep it just off the floor until you get to your intended target.



Step 4: When there, raise the axle to the correct height and roll into place. Carefully lower onto the workbench or (even better) The amazing Axle Stand Adapter, as seen here.



www.theAutoDolly.com 308-384-7423 ext. 188

MERRICK
The Auto Dolly & Merrick Originals

Parts Number: M998067

*Specifications subject to change without notice