

INSTRUCTIONS

© 2024, Speedway Motors, Inc.

SPEEDWAY
motors®

910-98207 - 1971-72 C10 Billet Throttle Pedal

KIT CONTENTS			
Qty	Description	P/N	Item #
1	Throttle Pedal Assembly	910-98207	1
1	Hardware Kit	910-98207.B	2

1971-72 C10 Billet Throttle Pedal Installation

Note: These instructions cover all finishes of the 91098207 throttle pedal assembly.

Remove all existing throttle linkage from vehicle. Remove existing throttle pedal assembly from firewall.

On the Speedway Motors pedal assembly, remove the flat head retaining bolt and washer from the left side of the pivot shaft and remove the lower pedal arm and pedal pad.

Position the pedal mount base with the upper arm to the inside of the firewall. The pedal assembly bolts to the firewall using the OEM mounting holes and the included 1/4-20 x 1-1/2" bolts.

The throttle cable (available separately from Speedway Motors) will be installed through an existing square factory hole. Install the throttle cable end fitting into the hole using the supplied tapered washers on each side of the firewall. Locate the cable to be in line with the hole in the upper arm and tighten the retaining nut. See cable installation instructions included with cable kit for details on completing the cable installation.

Once the cable installation is complete, including attachment to the throttle body or carburetor, open the throttle to the wide-open position. While holding the throttle open and the cable tight, install the pedal arm and pad onto the splined shaft in the wide open (contacting the floor) position. This will ensure that the throttle is fully open as the pedal reaches the floor. Confirm wide open throttle is reached and adjust as required. Once throttle opening is confirmed, replace the retaining washer and flat head screw to complete the install.

Caution: Check that there is no binding of the cable or pedal before starting or driving the vehicle. Using the pedal, open the throttle fully and confirm that it returns to the fully closed position several times before attempting to start the engine.

